

PacketCable™ 1.5 Specifications

Signaling MIB

PKT-SP-MIB-SIG1.5-C01-191120

CLOSED

Notice

This PacketCable specification is the result of a cooperative effort undertaken at the direction of Cable Television Laboratories, Inc. for the benefit of the cable industry and its customers. You may download, copy, distribute, and reference the documents herein only for the purpose of developing products or services in accordance with such documents, and educational use. Except as granted by CableLabs® in a separate written license agreement, no license is granted to modify the documents herein (except via the Engineering Change process), or to use, copy, modify or distribute the documents for any other purpose.

This document may contain references to other documents not owned or controlled by CableLabs. Use and understanding of this document may require access to such other documents. Designing, manufacturing, distributing, using, selling, or servicing products, or providing services, based on this document may require intellectual property licenses from third parties for technology referenced in this document. To the extent this document contains or refers to documents of third parties, you agree to abide by the terms of any licenses associated with such third-party documents, including open source licenses, if any.

© Copyright 2004-2019 Cable Television Laboratories, Inc.

All rights reserved.

DISCLAIMER

This document is furnished on an "AS IS" basis and neither CableLabs nor its members provides any representation or warranty, express or implied, regarding the accuracy, completeness, noninfringement, or fitness for a particular purpose of this document, or any document referenced herein. Any use or reliance on the information or opinion in this document is at the risk of the user, and CableLabs and its members shall not be liable for any damage or injury incurred by any person arising out of the completeness, accuracy, or utility of any information or opinion contained in the document.

CableLabs reserves the right to revise this document for any reason including, but not limited to, changes in laws, regulations, or standards promulgated by various entities, technology advances, or changes in equipment design, manufacturing techniques, or operating procedures described, or referred to, herein.

This document is not to be construed to suggest that any company modify or change any of its products or procedures, nor does this document represent a commitment by CableLabs or any of its members to purchase any product whether or not it meets the characteristics described in the document. Unless granted in a separate written agreement from CableLabs, nothing contained herein shall be construed to confer any license or right to any intellectual property. This document is not to be construed as an endorsement of any product or company or as the adoption or promulgation of any guidelines, standards, or recommendations.

Document Status Sheet

Document Control Number: PKT-SP-MIB-SIG1.5-C01-191120				
Document Title: Signaling MIB				
Revision History: D01 — Released September 30, 2004				
I01 — Issued January 28, 2005				
C01 — Closed November 20, 2019				
Date: November 20, 2019				
Status:	Work in Progress	Draft	Issued	Closed
Distribution Restrictions:	Author Only	GL/Member	GL/ PacketCable Vendor	Public

Key to Document Status Codes:

- Work in Progress** An incomplete document, designed to guide discussion and generate feedback that may include several alternative requirements for consideration.
- Draft** A document in specification format considered largely complete, but lacking review by Members and vendors. Drafts are susceptible to substantial change during the review process.
- Issued** A generally public document that has undergone Member and Technology Supplier review, cross-vendor interoperability, and is for Certification testing if applicable. Issued Specifications are subject to the Engineering Change Process.
- Closed** A static document, reviewed, tested, validated, and closed to further engineering change requests to the specification through CableLabs.

Trademarks:

CableLabs® is a registered trademark of Cable Television Laboratories, Inc. Other CableLabs marks are listed at <http://www.cablelabs.com/specs/certification/trademarks>. All other marks are the property of their respective owners.

Contents

- 1 SCOPE 5
- 2 REFERENCES 5
 - 2.1 Normative References 5
 - 2.2 Informative References..... 5
 - 2.3 Reference Acquisition 5
- 3 ABBREVIATIONS..... 5
- 4 REQUIREMENTS..... 6
- APPENDIX A. ACKNOWLEDGEMENTS..... 29

1 SCOPE

This specification describes the PacketCable Signaling (SIG) MIB requirements.

2 REFERENCES

In order to claim compliance with this specification, it is necessary to conform to the following standards and other works as indicated, in addition to the other requirements of this specification. Notwithstanding, intellectual property rights may be required to use or implement such normative references.

2.1 Normative References

- [1] PacketCable 1.5 MIB Framework, PKT-SP-MIBS1.5-C01-191120, November 20, 2019, Cable Television Laboratories, Inc.
- [2] PacketCable 1.5 Network-Based Call Signaling Protocol Specification, PKT-SP-NCS1.5-C01-191120, November 20, 2019, Cable Television Laboratories, Inc
- [3] PacketCable 1.5 MTA Device Provisioning Specification, PKT-SP-PROV1.5-C01-191120, November 20, 2019, Cable Television Laboratories, Inc.

2.2 Informative References

- [4] PacketCable 1.5 Architecture Framework Technical Report, PKT-TR-ARCH1.5-C01-191120, November 20, 2019, Cable Television Laboratories Inc.
- [5] IETF RFC 3261, SIP: Session Initiation Protocol, February 2002.

2.3 Reference Acquisition

- Cable Television Laboratories, Inc., 858 Coal Creek Circle, Louisville, CO 80027; Phone 303-661-9100; Fax 303-661-9199; Internet: www.cablelabs.com
- Internet Engineering Task Force (IETF) Secretariat c/o Corporation for National Research Initiatives, 1895 Preston White Drive, Suite 100, Reston, VA 20191-5434, Phone 703-620-8990, Fax 703-620-9071, Internet <http://www.ietf.org/>

3 ABBREVIATIONS

There are no abbreviations used in this document.

4 REQUIREMENTS

The PacketCable™ NCS MIB MUST be implemented as defined below.

```
PKTC-SIG-MIB DEFINITIONS ::= BEGIN

IMPORTS
    MODULE-IDENTITY,
    OBJECT-TYPE,
    Integer32,
    IPAddress,
    BITS
        FROM SNMPv2-SMI
    TEXTUAL-CONVENTION,
    RowStatus,
    TruthValue
        FROM SNMPv2-TC
    OBJECT-GROUP,
    MODULE-COMPLIANCE
        FROM SNMPv2-CONF
    SnpAdminString
        FROM SNMP-FRAMEWORK-MIB
    clabProjPacketCable
        FROM CLAB-DEF-MIB
    ifIndex
        FROM IF-MIB;

pktcSigMib MODULE-IDENTITY
    LAST-UPDATED      "200501280000Z" -- January 28, 2005
    ORGANIZATION      "CableLabs -- PacketCable OSS Group"
    CONTACT-INFO
        "Sumanth Channabasappa
        Postal: CableLabs, Inc.
             858 Coal Creek Circle
             Louisville, CO 80027-9750
             U.S.A.
        Phone:  +1 303-661-9100
        Fax:    +1 303-661-9199
        E-mail: mibs@cablelabs.com"

DESCRIPTION
    "This MIB module supplies the basic management
    object for the PacketCable Signaling
    protocols. This version of the MIB includes
    common signaling and Network Call Signaling
    (NCS) related signaling objects.
    Acknowledgements:
    Angela Lyda      Arris Interactive
    Sasha Medvinsky Motorola
    Roy Spitzer     Telogy Networks, Inc.
    Rick Vetter     Motorola
    Itay Sherman    Texas Instruments
    Klaus Hermanns  Cisco Systems
    Eugene Nechamkin Broadcom Corp.
    Satish Kumar    Texas Instruments
    Copyright 1999-2005 Cable Television Laboratories, Inc.
    All rights reserved."
    REVISION "200501280000Z"
    DESCRIPTION
        "This revision, published as part of the PacketCable
        1.5 Signaling MIB I01 Specification."
    ::= { clabProjPacketCable 2 }
```

```

PktcCodecType ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
    "Textual Convention defines various types of
    CODECs that MAY be supported. The list of CODECs
    MUST be consistent with the Codec RTP MAP Parameters
    Table in the PacketCable CODEC specification. In-line
    embedded comments below contain the Literal Codec Name
    for each CODEC. The Literal Codec Name corresponds to
    the second column of the Codec RTP MAP Parameters Table.
    The Literal Codec Name Column contains the CODEC name
    that is used in the LCD of the NCS messages CRCX/MDCX,
    and is also used to identify the CODEC in the CMS
    Provisioning Specification. The RTP Map Parameter
    Column of the Codec RTP MAP Parameters Table contains
    the string used in the media attribute line ('a=') of the
    SDP parameters in NCS messages."
REFERENCE
    "PacketCable CODEC Specification"
SYNTAX INTEGER {
    other (1),
    unknown (2),
    g729 (3), -- G729
    reserved (4), -- reserved for future use
    g729E (5), -- G729E
    pcmu (6), -- PCMU
    g726at32 (7), -- G726-32
    g728 (8), -- G728
    pcma (9), -- PCMA
    g726at16 (10), -- G726-16
    g726at24 (11), -- G726-24
    g726at40 (12), -- G726-40
    ilbc (13), -- iLBC
    bv16 (14) -- BV16
}

PktcRingCadence ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
    "This object represents a ring cadence in bit string
    format. The ring cadence representation starts with the
    first 1 in the pattern (the leading 0s in the MSB are
    padding and are to be ignored). Each bit
    represents 100ms of tone; 1 is tone, 0 is no tone. 64
    bits MUST be used for cadence representation, LSB 4 bits
    are used for representing repeatable characteristics.
    0000 means repeatable, and 1000 means non repeatable.
    During SNMP SET operations 64 bits MUST be used,
    otherwise MTA MUST reject the value. As an example, the
    hex representation of a ring cadence of 0.5 secs on; 4
    secs off; repeatable would be:0x0001F00000000000."
SYNTAX BITS {
    interval1 (0),
    interval2 (1),
    interval3 (2),
    interval4 (3),
    interval5 (4),
    interval6 (5),
    interval7 (6),
    interval8 (7),
    interval9 (8),
    interval10 (9),

```

```
interval11 (10),
interval12 (11),
interval13 (12),
interval14 (13),
interval15 (14),
interval16 (15),
interval17 (16),
interval18 (17),
interval19 (18),
interval20 (19),
interval21 (20),
interval22 (21),
interval23 (22),
interval24 (23),
interval25 (24),
interval26 (25),
interval27 (26),
interval28 (27),
interval29 (28),
interval30 (29),
interval31 (30),
interval32 (31),
interval33 (32),
interval34 (33),
interval35 (34),
interval36 (35),
interval37 (36),
interval38 (37),
interval39 (38),
interval40 (39),
interval41 (40),
interval42 (41),
interval43 (42),
interval44 (43),
interval45 (44),
interval46 (45),
interval47 (46),
interval48 (47),
interval49 (48),
interval50 (49),
interval51 (50),
interval52 (51),
interval53 (52),
interval54 (53),
interval55 (54),
interval56 (55),
interval57 (56),
interval58 (57),
interval59 (58),
interval60 (59),
interval61 (60),
interval62 (61),
interval63 (62),
interval64 (63)
```

```
}
```

```

PktcSigType ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "These are the various types of signaling that
        may be supported.
        ncs - network call signaling a derivation of MGCP
        (Media Gateway Control Protocol) version 1.0
        dcs - distributed call signaling a derivation
        of SIP (Session Initiation Protocol) RFC 3261"
    SYNTAX INTEGER {
        other(1),
        unknown(2),
        ncs(3),
        dcs(4)
    }

pktcSigMibObjects OBJECT IDENTIFIER
    ::= { pktcSigMib 1 }
pktcSigDevConfigObjects OBJECT IDENTIFIER
    ::= { pktcSigMibObjects 1 }
pktcNcsEndPntConfigObjects OBJECT IDENTIFIER
    ::= { pktcSigMibObjects 2 }
pktcSigEndPntConfigObjects OBJECT IDENTIFIER
    ::= { pktcSigMibObjects 3 }
pktcDcsEndPntConfigObjects OBJECT IDENTIFIER
    ::= { pktcSigMibObjects 4 }

--
-- The pktcSigDevCodecTable defines the codecs supported by this
-- Media Terminal Adapter (MTA). There is one entry for each
-- codecs supported.
--

pktcSigDevCodecTable OBJECT-TYPE
    SYNTAX SEQUENCE OF PktcSigDevCodecEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table describes the MTA supported codec types."
    ::= { pktcSigDevConfigObjects 1 }

pktcSigDevCodecEntry OBJECT-TYPE
    SYNTAX PktcSigDevCodecEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "List of supported codecs types for the MTA."
    INDEX { pktcSigDevCodecIndex }
    ::= { pktcSigDevCodecTable 1 }

PktcSigDevCodecEntry ::= SEQUENCE {
    pktcSigDevCodecIndex Integer32,
    pktcSigDevCodecType PktcCodecType,
    pktcSigDevCodecMax Integer32
}

pktcSigDevCodecIndex OBJECT-TYPE
    SYNTAX Integer32 (1..16383)
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "The index value which uniquely identifies an entry
        in the pktcSigDevCodecTable."

```

```

 ::= { pktcSigDevCodecEntry 1 }

pktcSigDevCodecType OBJECT-TYPE
    SYNTAX      PktcCodecType
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "A codec type supported by this MTA."
    ::= { pktcSigDevCodecEntry 2 }

pktcSigDevCodecMax OBJECT-TYPE
    SYNTAX      Integer32(1..16383)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The maximum number of simultaneous sessions of the
         specific codec that the MTA can support"
    ::= { pktcSigDevCodecEntry 3 }

--
--   These are the common signaling related definitions that affect
--   the entire MTA device.
--

pktcSigDevEchoCancellation OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies if the device is capable
         of echo cancellation."
    ::= { pktcSigDevConfigObjects 2 }

pktcSigDevSilenceSuppression OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies if the device is capable of
         silence suppression (Voice Activity Detection)."
    ::= { pktcSigDevConfigObjects 3 }

pktcSigDevConnectionMode OBJECT-TYPE
    SYNTAX BITS {
        voice(0),
        fax(1),
        modem(2)
    }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies the connection modes that the
         MTA device can support."
    ::= { pktcSigDevConfigObjects 4 }

--
--   In the United States Ring Cadences 0, 6, and 7 are custom
--   ring cadences definable by the user. The following three
--   objects are used for these definitions.

```



```

        "The default value used in the IP header for setting the
        Type of Service (TOS) value for call signalling."
REFERENCE
    "Refer to NCS specification"      DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 8 }

pktcSigDefMediaStreamTos OBJECT-TYPE
    SYNTAX      Integer32 (0..63)
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "This object contains the default value used in the IP
        header for setting the Type of Service (TOS) for media
        stream packets. The MTA MUST NOT update this object with
        the value supplied by the CMS in the NCS messages (if
        present). When the value of this object is updated by
        SNMP, the MTA MUST use the new value as a default starting
        from the new connection. Existing connections are not
        affected by the value's update."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 9 }

pktcSigTosFormatSelector OBJECT-TYPE
    SYNTAX      INTEGER {
        ipv4TOSOctet(1),
        dscpCodepoint(2)
    }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "The format of the default signaling and media
        Type of Service (TOS) values."
DEFVAL { ipv4TOSOctet }
 ::= { pktcSigDevConfigObjects 10 }

--
--      pktcSigCapabilityTable - This table defines the valid signaling
--      types supported by this MTA.
--

pktcSigCapabilityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktcSigCapabilityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the signaling types by this MTA."
 ::= { pktcSigDevConfigObjects 11 }

pktcSigCapabilityEntry OBJECT-TYPE
    SYNTAX      PktcSigCapabilityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Entries in pktcMtaDevSigCapabilityTable - List of
        supported signaling types, versions and vendor extensions
        for this MTA. Each entry in the list provides for one
        signaling type and version combination. If the device
        supports multiple versions of the same signaling type -
        it will require multiple entries."
    INDEX { pktcSignalingIndex }

```

```

 ::= { pktcSigCapabilityTable 1 }

PktcSigCapabilityEntry ::= SEQUENCE {
    pktcSignalingIndex      Integer32,
    pktcSignalingType       PktcSigType,
    pktcSignalingVersion    SnmpAdminString,
    pktcSignalingVendorExtension SnmpAdminString
}

pktcSignalingIndex      OBJECT-TYPE
    SYNTAX      Integer32 (1..16383)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "The index value which uniquely identifies
        an entry in the pktcSigCapabilityTable."
 ::= { pktcSigCapabilityEntry 1 }

pktcSignalingType       OBJECT-TYPE
    SYNTAX      PktcSigType
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The Type identifies the type of signaling
        used, this can be NCS, DCS, etc. This value
        has to be associated with a single signaling
        version - reference pktcMtaDevSignalingVersion."
 ::= { pktcSigCapabilityEntry 2 }

pktcSignalingVersion    OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Provides the version of the signaling type -
        reference pktcSignalingType. Examples
        would be 1.0 or 2.33 etc."
 ::= { pktcSigCapabilityEntry 3 }

pktcSignalingVendorExtension OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The vendor extension allows vendors to
        provide a list of additional capabilities,
        vendors can decide how to encode these
        Extensions, although space separated text is
        suggested."
 ::= { pktcSigCapabilityEntry 4 }

pktcSigDefNcsReceiveUdpPort OBJECT-TYPE
    SYNTAX      Integer32 (1025..65535)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object contains the MTA User Datagram Protocol
        (UDP) receive port that is being used for NCS call
        signaling. This object should only be changed by the
        configuration file."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 2427 }

```

```

 ::= { pktcSigDevConfigObjects 12 }

pktcSigServiceClassNameUS OBJECT-TYPE
SYNTAX      SnmpAdminString (SIZE (0..15))
MAX-ACCESS  read-write
STATUS      obsolete
DESCRIPTION
    "This object contains a string indicating the Service
    Class name to create an Upstream Service (US) Flow for
    NCS. If the object has an empty string value then the
    upstream NCS SF is not created and the best effort
    SF is used for upstream NCS data. The creation of the NCS
    SF primary occurs before Voice Communication Service is
    activated on the device. If this object is set to a
    non-empty (non-zero length) string, the MTA MUST create
    the NCS SF if it does not currently exist and the
    pktcSigServiceClassNameMask object has a non-zero value.
    If this object is subsequently set to an empty
    (zero-length)string , the MTA MUST delete the NCS SF
    if it exists. Setting this object to a different value
    does not cause the Upstream Service Flow to be
    re-created. The string MUST contain printable ASCII
    characters. The length of the string does not include a
    terminating zero. The MTA MUST append a terminating zero
    when the MTA creates the service flow. "
 ::= { pktcSigDevConfigObjects 13 }

pktcSigServiceClassNameDS OBJECT-TYPE
SYNTAX      SnmpAdminString (SIZE (0..15))
MAX-ACCESS  read-write
STATUS      obsolete
DESCRIPTION
    "This object contains a string indicating the Service
    Class Name to create a Downstream Service Flow for NCS.
    If the object has an empty string value then the
    NCS SF is not created and the best effort primary SF is
    used for downstream NCS data. The creation of the NCS SF
    occurs before Voice Communication Service is activated on
    the device. If this object is set to a non-empty (non-zero
    length) string, the MTA MUST create the NCS SF if it does
    not currently exist and the pktcSigServiceClassNameMask
    object has a non-zero value. If this object is
    subsequently set to an empty (zero-length) string, the MTA
    MUST delete the NCS SF if it exists. Setting this object
    to a different value does not cause the Downstream Service
    Flow to be re-created. The string MUST contain printable
    ASCII characters. The length of the string does not include
    a terminating zero. The MTA MUST append a terminating
    zero when the MTA creates the service flow. "
 ::= { pktcSigDevConfigObjects 14 }

pktcSigServiceClassNameMask OBJECT-TYPE
SYNTAX      Integer32
MAX-ACCESS  read-write
STATUS      obsolete
DESCRIPTION
    "This object contains a value for the Call Signaling
    Network Mask. The value is used as the NCS Call Signaling
    classifier mask. The object is used to delete the NCS SF
    when set to zero. When the object is set to a non-zero
    value by the SNMP Manager, the NCS SF are to be created."
DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 15 }

```



```

PktcSigEndPntConfigEntry ::= SEQUENCE {
    pktcSigEndPntCapabilityIndex      Integer32
}

pktcSigEndPntCapabilityIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..16383)
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "The associated index value in the pktcSigCapablityTable."
    ::= { pktcSigEndPntConfigEntry 1 }
--
-- The NCS End Point Config Table is used to define attributes that
-- are specific to connection EndPoints.
--
--

pktcNcsEndPntConfigTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktcNcsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the PacketCable EndPoint selected
        signaling type. The number of entries in this table
        represents the number of provisioned end points.
        For each conceptual row of pktcSigEndPntConfigTable
        defined, an associated row MUST be defined in one of
        the specific signaling tables such as
        pktcNcsEndPntConfigTable."
    ::= { pktcNcsEndPntConfigObjects 1 }

pktcNcsEndPntConfigEntry OBJECT-TYPE
    SYNTAX      PktcNcsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Entries in pktcNcsEndPntConfigTable - Each entry
        describes what signaling type a particular endpoint uses."
    INDEX { ifIndex }
    ::= { pktcNcsEndPntConfigTable 1 }

```

```

PktcNcsEndPntConfigEntry ::= SEQUENCE {
    pktcNcsEndPntConfigCallAgentId      SnmpAdminString,
    pktcNcsEndPntConfigCallAgentUdpPort Integer32,
    pktcNcsEndPntConfigPartialDialTO    Integer32,
    pktcNcsEndPntConfigCriticalDialTO   Integer32,
    pktcNcsEndPntConfigBusyToneTO       Integer32,
    pktcNcsEndPntConfigDialToneTO       Integer32,
    pktcNcsEndPntConfigMessageWaitingTO Integer32,
    pktcNcsEndPntConfigOffHookWarnToneTO Integer32,
    pktcNcsEndPntConfigRingingTO        Integer32,
    pktcNcsEndPntConfigRingBackTO       Integer32,
    pktcNcsEndPntConfigReorderToneTO    Integer32,
    pktcNcsEndPntConfigStutterDialToneTO Integer32,
    pktcNcsEndPntConfigTSMMax           Integer32,
    pktcNcsEndPntConfigMax1             Integer32,
    pktcNcsEndPntConfigMax2             Integer32,
    pktcNcsEndPntConfigMax1QEnable      TruthValue,
    pktcNcsEndPntConfigMax2QEnable      TruthValue,
    pktcNcsEndPntConfigMWD              Integer32,
    pktcNcsEndPntConfigTdinit           Integer32,
    pktcNcsEndPntConfigTdmin            Integer32,
    pktcNcsEndPntConfigTdmax            Integer32,
    pktcNcsEndPntConfigRtoMax           Integer32,
    pktcNcsEndPntConfigRtoInit          Integer32,
    pktcNcsEndPntConfigLongDurationKeepAlive Integer32,
    pktcNcsEndPntConfigThist            Integer32,
    pktcNcsEndPntConfigStatus           RowStatus,
    pktcNcsEndPntConfigCallWaitingMaxRep Integer32,
    pktcNcsEndPntConfigCallWaitingDelay Integer32,
    pktcNcsEndPntStatusCallIpAddress    IPAddress,
    pktcNcsEndPntStatusError            INTEGER
}

pktcNcsEndPntConfigCallAgentId      OBJECT-TYPE
    SYNTAX      SnmpAdminString(SIZE (3..255))
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains a string indicating the call agent
        name(e.g.: ca@abc.def.com). The call agent name
        after the character '@', MUST be a fully qualified
        domain name and MUST have a corresponding
        pktcMtaDevCmsFqdn entry in the pktcMtaDevCmsTable. For
        each particular end-point, the MTA MUST use the current
        value of this object to communicate with the corresponding
        CMS. The MTA MUST update this object with the value of the
        'Notified Entity' parameter of the NCS message. If the
        Notified Entity parameter does not contain a CallAgent
        port, the MTA MUST update this object with default value
        of 2727. Because of the high importance of this object to
        the ability of the MTA to maintain reliable NCS
        communication with the CMS, it is highly recommended not
        to change this object's value through management station
        during normal operations."

 ::= { pktcNcsEndPntConfigEntry 1 }

pktcNcsEndPntConfigCallAgentUdpPort      OBJECT-TYPE
    SYNTAX      Integer32 (1025..65535)
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the current value of the User
    
```

Datagram Protocol (UDP) receive port on which the call agent will receive NCS signaling from the endpoint. For each particular end-point, the MTA MUST use the current value of this object to communicate with the corresponding CMS. The MTA MUST update this object with the value of the 'Notified Entity' parameter of the NCS message. If the Notified Entity parameter does not contain a CallAgent port, the MTA MUST update this object with default value of 2727. Because of the high importance of this object to the ability of the MTA to maintain reliable NCS communication with the CMS, it is highly recommended not to change this object's value through management station during normal operations."

REFERENCE

"Refer to NCS specification"

DEFVAL { 2727 }

::= { pktcNcsEndPntConfigEntry 2 }

pktcNcsEndPntConfigPartialDialTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains maximum value of the partial dial time out."

REFERENCE

"Refer to PacketCable NCS specification"

DEFVAL { 16 }

::= { pktcNcsEndPntConfigEntry 3 }

pktcNcsEndPntConfigCriticalDialTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the maximum value of the critical dial time out."

REFERENCE

"Refer NCS specification"

DEFVAL { 4 }

::= { pktcNcsEndPntConfigEntry 4 }

pktcNcsEndPntConfigBusyToneTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the default timeout value for busy tone. The MTA MUST NOT update this object with the value provided in the NCS Message (if present). If the value of the object is modified by the SNMP Management Station, the MTA MUST use the new value as a default only for a new signal requested by the NCS message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 30 }

::= { pktcNcsEndPntConfigEntry 5 }

```

pktcNcsEndPntConfigDialToneTO      OBJECT-TYPE
    SYNTAX      Integer32
    UNITS        "seconds"
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "This object contains the default timeout value for dial
        tone. The MTA MUST NOT update this object with
        the value provided in the NCS Message (if present).
        If the value of the object is modified by the
        SNMP Management Station, the MTA MUST use the new value
        as a default only for a new signal requested by the NCS
        message."
    REFERENCE
        "Refer to NCS specification "
    DEFVAL      { 16 }
    ::= { pktcNcsEndPntConfigEntry 6 }

pktcNcsEndPntConfigMessageWaitingTO  OBJECT-TYPE
    SYNTAX      Integer32
    UNITS        "seconds"
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "This object contains the default timeout value for
        message waiting indicator The MTA MUST NOT
        update this object with the value provided in the NCS
        Message (if present). If the value of the object
        is modified by the SNMP Management Station, the MTA MUST
        use the new value as a default only for a new signal
        requested by the NCS message."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 16 }
    ::= { pktcNcsEndPntConfigEntry 7 }

pktcNcsEndPntConfigOffHookWarnToneTO  OBJECT-TYPE
    SYNTAX      Integer32
    UNITS        "seconds"
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "This object contains the default timeout value for the
        off hook Warning tone. The MTA MUST NOT update
        this object with the value provided in the NCS Message (if
        present). If the value of the object is modified
        by the SNMP Management Station, the MTA MUST use the new
        value as a default only for a new signal requested by the
        NCS message. "
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 0 }
    ::= { pktcNcsEndPntConfigEntry 8 }

pktcNcsEndPntConfigRingingTO         OBJECT-TYPE
    SYNTAX      Integer32
    UNITS        "seconds"
    MAX-ACCESS   read-create
    STATUS       current
    DESCRIPTION
        "This object contains the default timeout value for
        ringing. The MTA MUST NOT update this object with

```

the value provided in the NCS Message (if present).
 If the value of the object is modified by the
 SNMP Management Station, the MTA MUST use the new value
 as a default only for a new signal requested by the NCS
 message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 180 }

::= { pktcNcsEndPntConfigEntry 9 }

pktcNcsEndPntConfigRingBackTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the default timeout value for ring
 back. The MTA MUST NOT update this object with
 the value provided in the NCS Message (if present).
 If the value of the object is modified by the
 SNMP Management Station, the MTA MUST use the new value as
 a default only for a new signal requested by the NCS
 message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 180 }

::= { pktcNcsEndPntConfigEntry 10 }

pktcNcsEndPntConfigReorderToneTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the default timeout value for
 reorder tone. The MTA MUST NOT update this
 object with the value provided in the NCS Message (if
 present). If the value of the object is modified
 by the SNMP Management Station, the MTA MUST use the new
 value as a default only for a new signal requested by
 the NCS message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 30 }

::= { pktcNcsEndPntConfigEntry 11 }

pktcNcsEndPntConfigStutterDialToneTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the default timeout value for
 stutter dial tone. The MTA MUST NOT update this
 object with the value provided in the NCS Message (if
 present). If the value of the object is modified
 by the SNMP Management Station, the MTA MUST use the new
 value as a default only for a new signal requested by the
 NCS message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 16 }

::= { pktcNcsEndPntConfigEntry 12 }

```
pktcNcsEndPntConfigTSMMax      OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the max time in seconds since the
        sending of the initial datagram."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 20 }
    ::= { pktcNcsEndPntConfigEntry 13 }
```

```
pktcNcsEndPntConfigMax1      OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the suspicious error threshold
        for signaling messages."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 5 }
    ::= { pktcNcsEndPntConfigEntry 14 }
```

```
pktcNcsEndPntConfigMax2      OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the disconnect error
        threshold for signaling messages."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 7 }
    ::= { pktcNcsEndPntConfigEntry 15 }
```

```
pktcNcsEndPntConfigMax1QEnable  OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object enables/disables the Max1 Domain Name
        Server (DNS) query operation when Max1 expires."
    DEFVAL { true }
    ::= { pktcNcsEndPntConfigEntry 16 }
```

```
pktcNcsEndPntConfigMax2QEnable  OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object enables/disables the Max2 DNS query
        operation when Max2 expires."
    DEFVAL { true }
    ::= { pktcNcsEndPntConfigEntry 17 }
```

```
pktcNcsEndPntConfigMWD        OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
```

```

DESCRIPTION
    "Maximum Waiting Delay (MWD) contains the maximum
    number of seconds a MTA waits after a restart."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 600 }
 ::= { pktcNcsEndPntConfigEntry 18 }

```

```

pktcNcsEndPntConfigTdinit    OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the initial number of seconds
        a MTA waits after a disconnect."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 15 }
    ::= { pktcNcsEndPntConfigEntry 19 }

```

```

pktcNcsEndPntConfigTadmin    OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the minimum number of seconds a
        MTA waits after a disconnect."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 15 }
    ::= { pktcNcsEndPntConfigEntry 20 }

```

```

pktcNcsEndPntConfigTdmax     OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the maximum number of seconds
        a MTA waits after a disconnect."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 600 }
    ::= { pktcNcsEndPntConfigEntry 21 }

```

```

pktcNcsEndPntConfigRtoMax    OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the maximum number of seconds
        for the retransmission timer."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 4 }
    ::= { pktcNcsEndPntConfigEntry 22 }

```

```

pktcNcsEndPntConfigRtoInit    OBJECT-TYPE

```

```

SYNTAX      Integer32
UNITS       "milliseconds"
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "This object contains the initial number of seconds
    for the retransmission timer."
REFERENCE
    "Refer to NCS specification"
DEFVAL     { 200 }
 ::= { pktcNcsEndPntConfigEntry 23 }

pktcNcsEndPntConfigLongDurationKeepAlive      OBJECT-TYPE
SYNTAX      Integer32
UNITS       "minutes"
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "Specifies a timeout value in minutes for sending
    long duration call notification message."
REFERENCE
    "Refer to NCS specification"
DEFVAL     { 60 }
 ::= { pktcNcsEndPntConfigEntry 24 }

pktcNcsEndPntConfigThist      OBJECT-TYPE
SYNTAX      Integer32
UNITS       "seconds"
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "Timeout period in seconds before no response is
    declared."
REFERENCE
    "Refer to NCS specification"
DEFVAL     { 30 }
 ::= { pktcNcsEndPntConfigEntry 25 }

pktcNcsEndPntConfigStatus      OBJECT-TYPE
SYNTAX      RowStatus
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "This object contains the Row Status associated with
    the pktcNcsEndPntConfigTable."
 ::= { pktcNcsEndPntConfigEntry 26 }

pktcNcsEndPntConfigCallWaitingMaxRep      OBJECT-TYPE
SYNTAX      Integer32 (0..10)
MAX-ACCESS  read-create
STATUS      current
DESCRIPTION
    "This object contains the default value of the maximum
    number of repetitions of the call waiting tone that the
    MTA will play from a single CMS request. The MTA
    MUST NOT update this object with the information provided
    in the NCS Message (if present). If the value of
    the object is modified by the SNMP Management Station,
    the MTA MUST use the new value as a default only for a new
    signal requested by the NCS message."
DEFVAL     { 1 }
 ::= { pktcNcsEndPntConfigEntry 27 }

```

```

pktcNcsEndPntConfigCallWaitingDelay      OBJECT-TYPE
    SYNTAX      Integer32 (1..100)
    UNITS       "seconds"
    MAX-ACCESS   read-create
    STATUS      current
    DESCRIPTION
        "This object contains the delay between repetitions
         of the call waiting tone that the MTA will play from
         a single CMS request."
    DEFVAL      { 10 }
    ::= { pktcNcsEndPntConfigEntry 28 }

pktcNcsEndPntStatusCallIpAddress         OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "This object contains the IP address of the CMS
         currently being used for this endpoint. This IP
         address is used to create the appropriate security
         association."
    ::= { pktcNcsEndPntConfigEntry 29 }

pktcNcsEndPntStatusError                 OBJECT-TYPE
    SYNTAX      INTEGER {
        operational             (1),
        noSecurityAssociation   (2),
        disconnected             (3)
    }
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "This object contains the error status for this interface.
         The operational state indicates that all operations
         necessary to put the line in service have occurred and CMS
         has acknowledged the RSIP message successfully.
         If 'pktcMtaDevCmsIpsecCtrl' is enabled for the associated
         Call Agent, the noSecurityAssociation status indicates
         that no Security Association (SA) yet exists for this
         endpoint. Otherwise, the state is unused.
         The disconnected status indicates one of the following two:
         1. If 'pktcMtaDevCmsIpsecCtrl' is disabled then no
         security association is involved with this endpoint: the
         NCS signaling Software is in process of establishing the
         NCS signaling Link via an RSIP exchange.
         2. Otherwise, pktcMtaDevCmsIpsecCtrl is enabled, the
         security Association has been established and the NCS
         signaling Software is in process of establishing the NCS
         signaling Link via an RSIP exchange."
    ::= { pktcNcsEndPntConfigEntry 30 }

--
-- notification group is for future extension.
--
pktcSigNotificationPrefix OBJECT IDENTIFIER ::= { pktcSigMib 2 }
pktcSigNotification      OBJECT IDENTIFIER ::= {
    pktcSigNotificationPrefix 0 }
pktcSigConformance      OBJECT IDENTIFIER ::= { pktcSigMib 3 }
pktcSigCompliances      OBJECT IDENTIFIER ::= { pktcSigConformance 1 }
pktcSigGroups           OBJECT IDENTIFIER ::= { pktcSigConformance 2 }

-- compliance statements

```

```
pktcSigBasicCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "The compliance statement for devices that implement Signaling
        on the MTA."

MODULE -- pktcSigMib

-- unconditionally mandatory groups

MANDATORY-GROUPS {
    pktcSigGroup
}
GROUP pktcNcsGroup
DESCRIPTION
    "This group is mandatory for any MTA implementing NCS
    signaling"
 ::= { pktcSigCompliances 1 }

-- units of conformance

pktcSigGroup OBJECT-GROUP
    OBJECTS {
        pktcSigDevCodecType,
        pktcSigDevCodecMax,
        pktcSigDevEchoCancellation,
        pktcSigDevSilenceSuppression,
        pktcSigDevConnectionMode,
        pktcSigDevR0Cadence,
        pktcSigDevR6Cadence,
        pktcSigDevR7Cadence,
        pktcSigDefCallSigTos,
        pktcSigDefMediaStreamTos,
        pktcSigTosFormatSelector,
        pktcSignalingType,
        pktcSignalingVersion,
        pktcSignalingVendorExtension,
        pktcSigEndPntCapabilityIndex,
        pktcSigDefNcsReceiveUdpPort,
        pktcSigDevR1Cadence,
        pktcSigDevR2Cadence,
        pktcSigDevR3Cadence,
        pktcSigDevR4Cadence,
        pktcSigDevR5Cadence,
        pktcSigDevRgCadence,
        pktcSigDevRsCadence,
        pktcSigDevRtCadence
    }
    STATUS current
    DESCRIPTION
        "Group of objects for the common portion of the
        PacketCable Signaling MIB."
    ::= { pktcSigGroups 1 }
```

```

pktcNcsGroup OBJECT-GROUP
  OBJECTS {
    pktcNcsEndPntConfigCallAgentId,
    pktcNcsEndPntConfigCallAgentUdpPort,
    pktcNcsEndPntConfigPartialDialTO,
    pktcNcsEndPntConfigCriticalDialTO,
    pktcNcsEndPntConfigBusyToneTO,
    pktcNcsEndPntConfigDialToneTO,
    pktcNcsEndPntConfigMessageWaitingTO,
    pktcNcsEndPntConfigOffHookWarnToneTO,
    pktcNcsEndPntConfigRingingTO,
    pktcNcsEndPntConfigRingBackTO,
    pktcNcsEndPntConfigReorderToneTO,
    pktcNcsEndPntConfigStutterDialToneTO,
    pktcNcsEndPntConfigTSMMax,
    pktcNcsEndPntConfigMax1,
    pktcNcsEndPntConfigMax2,
    pktcNcsEndPntConfigMax1QEnable,
    pktcNcsEndPntConfigMax2QEnable,
    pktcNcsEndPntConfigMWD,
    pktcNcsEndPntConfigTdinit,
    pktcNcsEndPntConfigTdmin,
    pktcNcsEndPntConfigTdmax,
    pktcNcsEndPntConfigRtoMax,
    pktcNcsEndPntConfigRtoInit,
    pktcNcsEndPntConfigLongDurationKeepAlive,
    pktcNcsEndPntConfigThist,
    pktcNcsEndPntConfigStatus,
    pktcNcsEndPntConfigCallWaitingMaxRep,
    pktcNcsEndPntConfigCallWaitingDelay,
    pktcNcsEndPntStatusCallIpAddress,
    pktcNcsEndPntStatusError
  }
  STATUS current
  DESCRIPTION
    "Group of objects for the NCS portion of the
    PacketCable Signaling MIB. This is mandatory for
    NCS signaling."
    ::= { pktcSigGroups 2 }

pktcSigObsoleteGroup OBJECT-GROUP
  OBJECTS {
    pktcSigServiceClassNameUS,
    pktcSigServiceClassNameDS,
    pktcSigServiceClassNameMask,
    pktcSigNcsServiceFlowState
  }
  STATUS obsolete
  DESCRIPTION
    " Collection of obsolete objects for PacketCable
    Signaling MIB."
    ::= { pktcSigGroups 3}
END

```

Appendix A. Acknowledgements

The PacketCable project would like to acknowledge the members of the PacketCable OSS focus group whose efforts have been invaluable for creation of this document. In particular we wish to recognize and thank the following for their contribution to this document:

Angela Lyda (Arris Interactive)
Rick Morris (Arris Interactive)
Klaus Hermanns (Cisco Systems, Inc.)
Eugene Nechamkin (Broadcom Corp.)
Rick Vetter (Motorola, Inc.)
Sasha Medvinsky (Motorola, Inc)
Roy Spitzer (Telogy/TI)
Satish Kumar (Texas Instruments)
Itay Sherman (Texas Instruments)

Jean-Francois Mule, Sumanth Channabasappa, Venkatesh Sunkad (CableLabs, Inc.)