

PacketCable™ Signaling MIB Specification

PKT-SP-MIB-SIG-I08-040113

ISSUED

Superseded

Notice

This PacketCable specification is a cooperative effort undertaken at the direction of Cable Television Laboratories, Inc. (CableLabs®) for the benefit of the cable industry. Neither CableLabs, nor any other entity participating in the creation of this document, is responsible for any liability of any nature whatsoever resulting from or arising out of use or reliance upon this document by any party. This document is furnished on an AS-IS basis and neither CableLabs, nor other participating entity, provides any representation or warranty, express or implied, regarding its accuracy, completeness, or fitness for a particular purpose.

© Copyright 1999 - 2004 Cable Television Laboratories, Inc.
All rights reserved.

Document Status Sheet

Document Control Number: PKT-SP-MIB-SIG-I08-040113				
Document Title: PacketCable™ Signaling MIB Specification				
Revision History: I01 Released — December 1, 1999				
I02 Released — March 23, 2001				
I03 Released — December 21, 2001				
I04 Released — October 18, 2002				
I05 Released — November 27, 2002				
I06 Released — April 15, 2003				
I07 Released — July 28, 2003				
I08 Released — January 13, 2004				
Date: January 13, 2004				
Status:	Work in Progress	Draft	Issued	Closed
Distribution Restrictions:	Author Only	CL/Member	CL/ PacketCable Vendor	Public

Key to Document Status Codes:

- Work in Progress** An incomplete document, designed to guide discussion and generate feedback, that may include several alternative requirements for consideration.
- Draft** A document in specification format considered largely complete, but lacking review by Members and vendors. Drafts are susceptible to substantial change during the review process.
- Issued** A stable document, which has undergone rigorous member and vendor review and is suitable for product design and development, cross-vendor interoperability, and for certification testing.
- Closed** A static document, reviewed, tested, validated, and closed to further engineering change requests to the specification through CableLabs.

Trademarks:

DOCSIS®, eDOCSIS™, PacketCable™, CableHome™, OpenCable™, CableCARD™, and CableLabs® are trademarks of Cable Television Laboratories, Inc.

CONTENTS

1	SCOPE.....	1
2	REFERENCES.....	1
	2.1 Normative References	1
	2.2 Informative References	1
3	ABBREVIATIONS.....	1
4	REQUIREMENTS	2
	APPENDIX A. REVISION HISTORY	24

This page left blank intentionally.

1 SCOPE

This specification describes the PacketCable Signaling (SIG) MIB requirements.

2 REFERENCES

In order to claim compliance with this specification, it is necessary to conform to the following standards and other works as indicated, in addition to the other requirements of this specification. Notwithstanding, intellectual property rights may be required to use or implement such normative references.

2.1 Normative References

- [1] "PacketCable MIB Framework," PKT-SP-MIBS-I08-040113, January 13, 2004, Cable Television Laboratories, Inc., <http://www.packetcable.com/>
- [2] "PacketCable Network-Based Call Signaling Protocol Specification," PKT-SP-EC-MGCP-I09-040113, January 13, 2004, Cable Television Laboratories, Inc., <http://www.packetcable.com/>
- [3] "PacketCable MTA Device Provisioning Specification," PKT-SP-PROV-I08-040113, January 13, 2004, Cable Television Laboratories, Inc., <http://www.packetcable.com/>

2.2 Informative References

- [4] PacketCable Architecture Framework Technical Report, PKT-TR-ARCH-I01-991201, December 1, 1999, Cable Television Laboratories Inc., <http://www.PacketCable.com/>
- [5] IETF RFC 3261, SIP: Session Initiation Protocol, February 2002.

3 ABBREVIATIONS

There are no abbreviations used in this document.

4 REQUIREMENTS

The PacketCable™ NCS MIB MUST be implemented as defined below.

```

PKTC-SIG-MIB DEFINITIONS ::= BEGIN

IMPORTS
    MODULE-IDENTITY,
    OBJECT-TYPE,
    Integer32,
    IPAddress
        FROM SNMPv2-SMI
    TEXTUAL-CONVENTION,
    RowStatus,
    TruthValue
        FROM SNMPv2-TC
    OBJECT-GROUP,
    MODULE-COMPLIANCE
        FROM SNMPv2-CONF
    SnmpAdminString
        FROM SNMP-FRAMEWORK-MIB
    clabProjPacketCable
        FROM CLAB-DEF-MIB
    ifIndex
        FROM IF-MIB;

pktcSigMib MODULE-IDENTITY
    LAST-UPDATED      "200401130000Z" -- January 13, 2004
    ORGANIZATION      "CableLabs - PacketCable OSS Group"
    CONTACT-INFO
        "Venkatesh Sunkad
        Postal: CableLabs, Inc.
              400 Centennial Parkway
              Louisville, CO 80027-1266
              U.S.A.
        Phone: +1 303-661-9100
        Fax:   +1 303-661-9199
        E-mail: mibs@cablelabs.com"

DESCRIPTION
    "This MIB module supplies the basic management
    object for the PacketCable Signaling
    protocols. This version of the MIB includes
    common signaling and Network Call Signaling
    (NCS) related signaling objects.
    Acknowledgements:
    Angela Lyda      Arris Interactive
    Sasha Medvinsky  Motorola
    Roy Spitzer      Telogy Networks, Inc.
    Rick Vetter      Motorola
    Itay Sherman     Texas Instruments
    Klaus Hermanns   Cisco Systems
    Eugene Nechamkin Broadcom Corp.
    Satish Kumar     Texas Instruments
    Copyright 1999-2004 Cable Television Laboratories, Inc.
    All rights reserved."
    REVISION "200401130000Z"
    DESCRIPTION
        "This revision, published as part of the PacketCable
        Signaling MIB I08 Specification."

```

```
 ::= { clabProjPacketCable 2 }

PktcCodecType ::= TEXTUAL-CONVENTION
STATUS        current
DESCRIPTION   "Textual Convention defines various types of
CODECs that MAY be supported. The list of CODECs
MUST be consistent with the Codec RTP MAP Parameters
Table in the PacketCable CODEC specification. In-line
embedded comments below contain the Literal Codec Name
for each CODEC. The Literal Codec Name corresponds to
the second column of the Codec RTP MAP Parameters Table.
The Literal Codec Name Column contains the CODEC name
that is used in the LCD of the NCS messages CRCX/MDCX,
and is also used to identify the CODEC in the CMS
Provisioning Specification. The RTP Map Parameter
Column of the Codec RTP MAP Parameters Table contains
the string used in the media attribute line ('a=') of the
SDP parameters in NCS messages."
REFERENCE     "PacketCable CODEC Specification"
SYNTAX        INTEGER {
    other      (1),
    unknown   (2),
    g729       (3), -- G729
    reserved  (4), -- reserved for future use
    g729E     (5), -- G729E
    pcmu      (6), -- PCMU
    g726at32  (7), -- G726-32
    g728      (8), -- G728
    pcma      (9), -- PCMA
    g726at16  (10), -- G726-16
    g726at24  (11), -- G726-24
    g726at40  (12) -- G726-40
}

PktcRingCadence ::= TEXTUAL-CONVENTION
STATUS          current
DESCRIPTION     "This object represents a ring cadence in bit string
format. The ring cadence representation starts with the
first 1 in the pattern (the leading 0s in the MSB are
padding and are to be ignored). Each bit
represents 100ms of tone; 1 is tone, 0 is no tone. 64
bits MUST be used for cadence representation, LSB 4 bits
are used for representing repeatable characteristics.
0000 means repeatable, and 1000 means non repeatable.
During SNMP SET operations 64 bits MUST be used,
otherwise MTA MUST reject the value. As an example, the
hex representation of a ring cadence of 0.5 secs on; 4
secs off; repeatable would be:0x0001F00000000000."
SYNTAX         BITS {
    interval1 (0),
    interval2 (1),
    interval3 (2),
    interval4 (3),
    interval5 (4),
    interval6 (5),
    interval7 (6),
    interval8 (7),
    interval9 (8),
    interval10 (9),
    interval11 (10),
}
```

```
interval12 (11),
interval13 (12),
interval14 (13),
interval15 (14),
interval16 (15),
interval17 (16),
interval18 (17),
interval19 (18),
interval20 (19),
interval21 (20),
interval22 (21),
interval23 (22),
interval24 (23),
interval25 (24),
interval26 (25),
interval27 (26),
interval28 (27),
interval29 (28),
interval30 (29),
interval31 (30),
interval32 (31),
interval33 (32),
interval34 (33),
interval35 (34),
interval36 (35),
interval37 (36),
interval38 (37),
interval39 (38),
interval40 (39),
interval41 (40),
interval42 (41),
interval43 (42),
interval44 (43),
interval45 (44),
interval46 (45),
interval47 (46),
interval48 (47),
interval49 (48),
interval50 (49),
interval51 (50),
interval52 (51),
interval53 (52),
interval54 (53),
interval55 (54),
interval56 (55),
interval57 (56),
interval58 (57),
interval59 (58),
interval60 (59),
interval61 (60),
interval62 (61),
interval63 (62),
interval64 (63)
}
```

```

PktcSigType      ::= TEXTUAL-CONVENTION
    STATUS        current
    DESCRIPTION
        "These are the various types of signaling that
        may be supported.
        ncs - network call signaling a derivation of MGCP
        (Media Gateway Control Protocol) version 1.0
        dcs - distributed call signaling a derivation
        of SIP (Session Initiation Protocol) RFC 3261"
    SYNTAX INTEGER {
        other(1),
        unknown(2),
        ncs(3),
        dcs(4)
    }

pktcSigMibObjects      OBJECT IDENTIFIER
                        ::= { pktcSigMib 1 }
pktcSigDevConfigObjects OBJECT IDENTIFIER
                        ::= { pktcSigMibObjects 1 }
pktcNcsEndPntConfigObjects OBJECT IDENTIFIER
                        ::= { pktcSigMibObjects 2 }
pktcSigEndPntConfigObjects OBJECT IDENTIFIER
                        ::= { pktcSigMibObjects 3 }
pktcDcsEndPntConfigObjects OBJECT IDENTIFIER
                        ::= { pktcSigMibObjects 4 }

--
--      The pktcSigDevCodecTable defines the codecs supported by this
--      Media Terminal Adapter (MTA).  There is one entry for each
--      codecs supported.
--

pktcSigDevCodecTable  OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktcSigDevCodecEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the MTA supported codec types."
    ::= { pktcSigDevConfigObjects 1 }

pktcSigDevCodecEntry OBJECT-TYPE
    SYNTAX      PktcSigDevCodecEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "List of supported codecs types for the MTA."
    INDEX { pktcSigDevCodecIndex }
    ::= { pktcSigDevCodecTable 1 }

PktcSigDevCodecEntry ::= SEQUENCE {
    pktcSigDevCodecIndex  Integer32,
    pktcSigDevCodecType   PktcCodecType,
    pktcSigDevCodecMax    Integer32
}

pktcSigDevCodecIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..16383)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "The index value which uniquely identifies an entry
        in the pktcSigDevCodecTable."

```

```

 ::= { pktcSigDevCodecEntry 1 }

pktcSigDevCodecType OBJECT-TYPE
    SYNTAX      PktcCodecType
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "A codec type supported by this MTA."
    ::= { pktcSigDevCodecEntry 2 }

pktcSigDevCodecMax OBJECT-TYPE
    SYNTAX      Integer32(1..16383)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The maximum number of simultaneous sessions of the
         specific codec that the MTA can support"
    ::= { pktcSigDevCodecEntry 3 }

--
--   These are the common signaling related definitions that affect
--   the entire MTA device.
--

pktcSigDevEchoCancellation OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies if the device is capable
         of echo cancellation."
    ::= { pktcSigDevConfigObjects 2 }

pktcSigDevSilenceSuppression OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies if the device is capable of
         silence suppression (Voice Activity Detection)."
    ::= { pktcSigDevConfigObjects 3 }

pktcSigDevConnectionMode OBJECT-TYPE
    SYNTAX BITS {
        voice(0),
        fax(1),
        modem(2)
    }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object specifies the connection modes that the
         MTA device can support."
    ::= { pktcSigDevConfigObjects 4 }

--
--   In the United States Ring Cadences 0, 6, and 7 are custom
--   ring cadences definable by the user. The following three
--   objects are used for these definitions.
--

```



```

        Type of Service (TOS) value for call signalling."
REFERENCE
    "Refer to NCS specification"      DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 8 }

pktcSigDefMediaStreamTos OBJECT-TYPE
SYNTAX      Integer32 (0..63)
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "The default value used in the IP header for setting
    the Type of Service (TOS) value for media stream packets."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 9 }

pktcSigTosFormatSelector OBJECT-TYPE
SYNTAX      INTEGER {
            ipv4TOSOctet(1),
            dscpCodepoint(2)
        }
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "The format of the default signaling and media
    Type of Service (TOS) values."
DEFVAL { ipv4TOSOctet }
 ::= { pktcSigDevConfigObjects 10 }

--
--      pktcSigCapabilityTable - This table defines the valid signaling
--      types supported by this MTA.
--

pktcSigCapabilityTable OBJECT-TYPE
SYNTAX      SEQUENCE OF PktcSigCapabilityEntry
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION
    "This table describes the signaling types by this MTA."
 ::= { pktcSigDevConfigObjects 11 }

pktcSigCapabilityEntry OBJECT-TYPE
SYNTAX      PktcSigCapabilityEntry
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION
    "Entries in pktcMtaDevSigCapabilityTable - List of
    supported signaling types, versions and vendor extensions
    for this MTA. Each entry in the list provides for one
    signaling type and version combination. If the device
    supports multiple versions of the same signaling type -
    it will require multiple entries."
INDEX { pktcSignalingIndex }
 ::= { pktcSigCapabilityTable 1 }

PktcSigCapabilityEntry ::= SEQUENCE {
    pktcSignalingIndex      Integer32,
    pktcSignalingType       PktcSigType,
    pktcSignalingVersion    SnmpAdminString,
    pktcSignalingVendorExtension SnmpAdminString
}

```

```
pktcSignalingIndex      OBJECT-TYPE
    SYNTAX      Integer32 (1..16383)
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "The index value which uniquely identifies
         an entry in the pktcSigCapabilityTable."
    ::= { pktcSigCapabilityEntry 1 }

pktcSignalingType       OBJECT-TYPE
    SYNTAX      PkctcSigType
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "The Type identifies the type of signaling
         used, this can be NCS, DCS, etc. This value
         has to be associated with a single signaling
         version - reference pktcMtaDevSignalingVersion."
    ::= { pktcSigCapabilityEntry 2 }

pktcSignalingVersion    OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "Provides the version of the signaling type -
         reference pktcSignalingType. Examples
         would be 1.0 or 2.33 etc."
    ::= { pktcSigCapabilityEntry 3 }

pktcSignalingVendorExtension OBJECT-TYPE
    SYNTAX      SnmpAdminString
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "The vendor extension allows vendors to
         provide a list of additional capabilities,
         vendors can decide how to encode these
         Extensions, although space separated text is
         suggested."
    ::= { pktcSigCapabilityEntry 4 }

pktcSigDefNcsReceiveUdpPort OBJECT-TYPE
    SYNTAX      Integer32 (1025..65535)
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "This object contains the MTA User Datagram Protocol
         (UDP) receive port that is being used for NCS call
         signaling. This object should only be changed by the
         configuration file."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 2427 }
    ::= { pktcSigDevConfigObjects 12 }

pktcSigServiceClassNameUS OBJECT-TYPE
    SYNTAX      SnmpAdminString (SIZE (0..15))
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "This object contains a string indicating the Service
```

```

Class name to create an Upstream Service (US) Flow for
NCS. If the object has an empty string value then the
upstream NCS SF is not created and the best effort
SF is used for upstream NCS data. The creation of the NCS
SF primary occurs before Voice Communication Service is
activated on the device. If this object is set to a
non-empty (non-zero length) string, the MTA MUST create
the NCS SF if it does not currently exist and the
pktcSigServiceClassNameMask object has a non-zero value.
If this object is subsequently set to an empty
(zero-length)string, the MTA MUST delete the NCS SF
if it exists. Setting this object to a different value
does not cause the Upstream Service Flow to be
re-created. The string MUST contain printable ASCII
characters. The length of the string does not include a
terminating zero. The MTA MUST append a terminating zero
when the MTA creates the service flow. "
 ::= { pktcSigDevConfigObjects 13 }

pktcSigServiceClassNameDS OBJECT-TYPE
SYNTAX SnmpAdminString (SIZE (0..15))
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "This object contains a string indicating the Service
    Class Name to create a Downstream Service Flow for NCS.
    If the object has an empty string value then the
    NCS SF is not created and the best effort primary SF is
    used for downstream NCS data. The creation of the NCS SF
    occurs before Voice Communication Service is activated on
    the device. If this object is set to a non-empty (non-zero
    length) string, the MTA MUST create the NCS SF if it does
    not currently exist and the pktcSigServiceClassNameMask
    object has a non-zero value. If this object is
    subsequently set to an empty (zero-length) string, the MTA
    MUST delete the NCS SF if it exists. Setting this object
    to a different value does not cause the Downstream Service
    Flow to be re-created. The string MUST contain printable
    ASCII characters. The length of the string does not include
    a terminating zero. The MTA MUST append a terminating
    zero when the MTA creates the service flow. "
 ::= { pktcSigDevConfigObjects 14 }

pktcSigServiceClassNameMask OBJECT-TYPE
SYNTAX Integer32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "This object contains a value for the Call Signaling
    Network Mask. The value is used as the NCS Call Signaling
    classifier mask. The object is used to delete the NCS SF
    when set to zero. When the object is set to a non-zero
    value by the SNMP Manager, the NCS SF are to be created."
DEFVAL { 0 }
 ::= { pktcSigDevConfigObjects 15 }

pktcSigNcsServiceFlowState OBJECT-TYPE
SYNTAX INTEGER {
    notactive (1),
    active (2),
    error (3)
}
MAX-ACCESS read-only

```



```

        "The associated index value in the pktcSigCapablityTable."
 ::= { pktcSigEndPntConfigEntry 1 }
--
-- The NCS End Point Config Table is used to define attributes that
-- are specific to connection EndPoints.
--
--

pktcNcsEndPntConfigTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktcNcsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the PacketCable EndPoint selected
        signaling type. The number of entries in this table
        represents the number of provisioned end points.
        For each conceptual row of pktcSigEndPntConfigTable
        defined, an associated row MUST be defined in one of
        the specific signaling tables such as
        pktcNcsEndPntConfigTable."
 ::= { pktcNcsEndPntConfigObjects 1 }

pktcNcsEndPntConfigEntry OBJECT-TYPE
    SYNTAX      PktcNcsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Entries in pktcNcsEndPntConfigTable - Each entry
        describes what signaling type a particular endpoint uses."
    INDEX { ifIndex }
 ::= { pktcNcsEndPntConfigTable 1 }

PktcNcsEndPntConfigEntry ::= SEQUENCE {
    pktcNcsEndPntConfigCallAgentId          SnmpAdminString,
    pktcNcsEndPntConfigCallAgentUdpPort     Integer32,
    pktcNcsEndPntConfigPartialDialTO       Integer32,
    pktcNcsEndPntConfigCriticalDialTO      Integer32,
    pktcNcsEndPntConfigBusyToneTO          Integer32,
    pktcNcsEndPntConfigDialToneTO          Integer32,
    pktcNcsEndPntConfigMessageWaitingTO    Integer32,
    pktcNcsEndPntConfigOffHookWarnToneTO   Integer32,
    pktcNcsEndPntConfigRingingTO           Integer32,
    pktcNcsEndPntConfigRingBackTO          Integer32,
    pktcNcsEndPntConfigReorderToneTO       Integer32,
    pktcNcsEndPntConfigStutterDialToneTO   Integer32,
    pktcNcsEndPntConfigTSMMax              Integer32,
    pktcNcsEndPntConfigMax1                Integer32,
    pktcNcsEndPntConfigMax2                Integer32,
    pktcNcsEndPntConfigMax1QEnable         TruthValue,
    pktcNcsEndPntConfigMax2QEnable         TruthValue,
    pktcNcsEndPntConfigMWD                 Integer32,
    pktcNcsEndPntConfigTdinit               Integer32,
    pktcNcsEndPntConfigTdmin                Integer32,
    pktcNcsEndPntConfigTdmax                Integer32,
    pktcNcsEndPntConfigRtoMax              Integer32,
    pktcNcsEndPntConfigRtoInit              Integer32,
    pktcNcsEndPntConfigLongDurationKeepAlive Integer32,
    pktcNcsEndPntConfigThist                Integer32,
    pktcNcsEndPntConfigStatus               RowStatus,
    pktcNcsEndPntConfigCallWaitingMaxRep   Integer32,
    pktcNcsEndPntConfigCallWaitingDelay    Integer32,
    pktcNcsEndPntStatusCallIpAddress       IPAddress,
    pktcNcsEndPntStatusError                INTEGER
}

```

```

    }

pktcNcsEndPntConfigCallAgentId      OBJECT-TYPE
    SYNTAX      SnmpAdminString(SIZE (3..255))
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains a string indicating the call agent
        name(ex: ca@abc.def.com). The call agent name
        after the character '@' MUST be a fully qualified
        domain name and MUST have a corresponding
        pktcMtaDevCmsFqdn entry in the pktcMtaDevCmsTable."

    ::= { pktcNcsEndPntConfigEntry 1 }

pktcNcsEndPntConfigCallAgentUdpPort  OBJECT-TYPE
    SYNTAX      Integer32 (1025..65535)
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the call agent User Datagram
        Protocol (UDP) receive port that is being used for
        this instance of call signaling, i.e. the default port
        on which the call agent will receive NCS signaling from
        the gateway."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 2727 }
    ::= { pktcNcsEndPntConfigEntry 2 }

pktcNcsEndPntConfigPartialDialTO     OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains maximum value of the partial
        dial time out."
    REFERENCE
        "Refer to PacketCable NCS specification"
    DEFVAL      { 16 }
    ::= { pktcNcsEndPntConfigEntry 3 }

pktcNcsEndPntConfigCriticalDialTO    OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the maximum value of the critical
        dial time out."
    REFERENCE
        "Refer NCS specification"
    DEFVAL      { 4 }
    ::= { pktcNcsEndPntConfigEntry 4 }

pktcNcsEndPntConfigBusyToneTO        OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the timeout value for busy tone."

```

```

REFERENCE
    "Refer to NCS specification"
DEFVAL    { 30 }
 ::= { pktcNcsEndPntConfigEntry 5 }

pktcNcsEndPntConfigDialToneTO      OBJECT-TYPE
SYNTAX   Integer32
UNITS    "seconds"
MAX-ACCESS  read-create
STATUS   current
DESCRIPTION
    "This object contains the timeout value for dial tone."
REFERENCE
    "Refer to NCS specification "
DEFVAL    { 16 }
 ::= { pktcNcsEndPntConfigEntry 6 }

pktcNcsEndPntConfigMessageWaitingTO      OBJECT-TYPE
SYNTAX   Integer32
UNITS    "seconds"
MAX-ACCESS  read-create
STATUS   current
DESCRIPTION
    "This object contains the timeout value for message
    waiting indicator."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 16 }
 ::= { pktcNcsEndPntConfigEntry 7 }

pktcNcsEndPntConfigOffHookWarnToneTO      OBJECT-TYPE
SYNTAX   Integer32
UNITS    "seconds"
MAX-ACCESS  read-create
STATUS   current
DESCRIPTION
    "This object contains the timeout value for
    the off hook Warning tone."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 0 }
 ::= { pktcNcsEndPntConfigEntry 8 }

pktcNcsEndPntConfigRingingTO      OBJECT-TYPE
SYNTAX   Integer32
UNITS    "seconds"
MAX-ACCESS  read-create
STATUS   current
DESCRIPTION
    "This object contains the timeout value for ringing."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 180 }
 ::= { pktcNcsEndPntConfigEntry 9 }

pktcNcsEndPntConfigRingBackTO      OBJECT-TYPE
SYNTAX   Integer32
UNITS    "seconds"
MAX-ACCESS  read-create
STATUS   current
DESCRIPTION
    "This object contains the timeout value for ring back."
REFERENCE

```

```
        "Refer to NCS specification"
DEFVAL    { 180 }
 ::= { pktcNcsEndPntConfigEntry 10 }

pktcNcsEndPntConfigReorderToneTO    OBJECT-TYPE
SYNTAX    Integer32
UNITS     "seconds"
MAX-ACCESS    read-create
STATUS    current
DESCRIPTION
    "This object contains the timeout value for reorder tone."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 30 }
 ::= { pktcNcsEndPntConfigEntry 11 }

pktcNcsEndPntConfigStutterDialToneTO    OBJECT-TYPE
SYNTAX    Integer32
UNITS     "seconds"
MAX-ACCESS    read-create
STATUS    current
DESCRIPTION
    "This object contains the timeout value for stutter
    dial tone."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 16 }
 ::= { pktcNcsEndPntConfigEntry 12 }

pktcNcsEndPntConfigTSMMax    OBJECT-TYPE
SYNTAX    Integer32
MAX-ACCESS    read-create
STATUS    current
DESCRIPTION
    "This object contains the max time in seconds since the
    sending of the initial datagram."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 20 }
 ::= { pktcNcsEndPntConfigEntry 13 }

pktcNcsEndPntConfigMax1    OBJECT-TYPE
SYNTAX    Integer32
MAX-ACCESS    read-create
STATUS    current
DESCRIPTION
    "This object contains the suspicious error threshold
    for signaling messages."
REFERENCE
    "Refer to NCS specification"
DEFVAL    { 5 }
 ::= { pktcNcsEndPntConfigEntry 14 }
```

```

pktcNcsEndPntConfigMax2      OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the disconnect error
        threshold for signaling messages."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 7 }
    ::= { pktcNcsEndPntConfigEntry 15 }

pktcNcsEndPntConfigMax1QEnable  OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object enables/disables the Max1 Domain Name
        Server (DNS) query operation when Max1 expires."
    DEFVAL { true }
    ::= { pktcNcsEndPntConfigEntry 16 }

pktcNcsEndPntConfigMax2QEnable  OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object enables/disables the Max2 DNS query
        operation when Max2 expires."
    DEFVAL { true }
    ::= { pktcNcsEndPntConfigEntry 17 }

pktcNcsEndPntConfigMWD      OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "Maximum Waiting Delay (MWD) contains the maximum
        number of seconds a MTA waits after a restart."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 600 }
    ::= { pktcNcsEndPntConfigEntry 18 }

pktcNcsEndPntConfigTdinit    OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the initial number of seconds
        a MTA waits after a disconnect."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 15 }
    ::= { pktcNcsEndPntConfigEntry 19 }

pktcNcsEndPntConfigTdmin     OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"

```

```
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the minimum number of seconds a
              MTA waits after a disconnect."
REFERENCE     "Refer to NCS specification"
DEFVAL { 15 }
 ::= { pktcNcsEndPntConfigEntry 20 }

pktcNcsEndPntConfigTdma OBJECT-TYPE
SYNTAX        Integer32
UNITS         "seconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the maximum number of seconds
              a MTA waits after a disconnect."
REFERENCE     "Refer to NCS specification"
DEFVAL { 600 }
 ::= { pktcNcsEndPntConfigEntry 21 }

pktcNcsEndPntConfigRtoMax OBJECT-TYPE
SYNTAX        Integer32
UNITS         "seconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the maximum number of seconds
              for the retransmission timer."
REFERENCE     "Refer to NCS specification"
DEFVAL { 4 }
 ::= { pktcNcsEndPntConfigEntry 22 }

pktcNcsEndPntConfigRtoInit OBJECT-TYPE
SYNTAX        Integer32
UNITS         "milliseconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the initial number of seconds
              for the retransmission timer."
REFERENCE     "Refer to NCS specification"
DEFVAL { 200 }
 ::= { pktcNcsEndPntConfigEntry 23 }

pktcNcsEndPntConfigLongDurationKeepAlive OBJECT-TYPE
SYNTAX        Integer32
UNITS         "minutes"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "Specifies a timeout value in minutes for sending
              long duration call notification message."
REFERENCE     "Refer to NCS specification"
DEFVAL { 60 }
 ::= { pktcNcsEndPntConfigEntry 24 }
```

```

pktcNcsEndPntConfigThist OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "Timeout period in seconds before no response is
        declared."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 30 }
    ::= { pktcNcsEndPntConfigEntry 25 }

pktcNcsEndPntConfigStatus OBJECT-TYPE
    SYNTAX      RowStatus
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the Row Status associated with
        the pktsNcsEndPntTable."
    ::= { pktcNcsEndPntConfigEntry 26 }

pktcNcsEndPntConfigCallWaitingMaxRep OBJECT-TYPE
    SYNTAX      Integer32 (0..10)
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the maximum number of repetitions
        of the call waiting tone that the MTA will play from a
        single CMS request. A value of zero (0) can be used if
        the CMS is to control the repetitions of the call
        waiting tone."
    DEFVAL     { 1 }
    ::= { pktcNcsEndPntConfigEntry 27 }

pktcNcsEndPntConfigCallWaitingDelay OBJECT-TYPE
    SYNTAX      Integer32 (1..100)
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the delay between repetitions
        of the call waiting tone that the MTA will play from
        a single CMS request."
    DEFVAL     { 10 }
    ::= { pktcNcsEndPntConfigEntry 28 }

pktcNcsEndPntStatusCallIpAddress OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "This object contains the IP address of the CMS
        currently being used for this endpoint. This IP
        address is used to create the appropriate security
        association."
    ::= { pktcNcsEndPntConfigEntry 29 }

pktcNcsEndPntStatusError OBJECT-TYPE
    SYNTAX      INTEGER {
        operational             (1),
        noSecurityAssociation (2),
        disconnected             (3)
    }

```

```

}
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object contains the error status for this interface.
    The operational state indicates that all operations
    necessary to put the line in service have occurred and CMS
    has acknowledged the RSIP message successfully.
    If 'pktcMtaDevCmsIpssecCtrl' is enabled for the associated
    Call Agent, the noSecurityAssociation status indicates
    that no Security Association (SA) yet exists for this
    endpoint. Otherwise, the state is unused.
    The disconnected status indicates one of the following two:
    1. If 'pktcMtaDevCmsIpssecCtrl' is disabled then no
    security association is involved with this endpoint: the
    NCS signaling Software is in process of establishing the
    NCS signaling Link via an RSIP exchange.
    2. Otherwise, pktcMtaDevCmsIpssecCtrl is enabled, the
    Security Association has been established and the NCS
    signaling Software is in process of establishing the NCS
    signaling Link via an RSIP exchange."

    ::= { pktcNcsEndPntConfigEntry 30 }
--
-- notification group is for future extension.
--
pktcSigNotificationPrefix OBJECT IDENTIFIER ::= { pktcSigMib 2 }
pktcSigNotification OBJECT IDENTIFIER ::= {
    pktcSigNotificationPrefix 0 }
pktcSigConformance OBJECT IDENTIFIER ::= { pktcSigMib 3 }
pktcSigCompliances OBJECT IDENTIFIER ::= { pktcSigConformance 1 }
pktcSigGroups OBJECT IDENTIFIER ::= { pktcSigConformance 2 }

-- compliance statements

pktcSigBasicCompliance MODULE-COMPLIANCE
    STATUS          current
    DESCRIPTION
        "The compliance statement for devices that implement Signaling
        on the MTA."

MODULE -- pktcSigMib

-- unconditionally mandatory groups

MANDATORY-GROUPS {
    pktcSigGroup
}
GROUP pktcNcsGroup
DESCRIPTION
    "This group is mandatory for any MTA implementing NCS
    signaling"
::={ pktcSigCompliances 1 }

-- units of conformance

```

```
pktcSigGroup OBJECT-GROUP
  OBJECTS {
    pktcSigDevCodecType,
    pktcSigDevCodecMax,
    pktcSigDevEchoCancellation,
    pktcSigDevSilenceSuppression,
    pktcSigDevConnectionMode,
    pktcSigDevR0Cadence,
    pktcSigDevR6Cadence,
    pktcSigDevR7Cadence,
    pktcSigDefCallSigTos,
    pktcSigDefMediaStreamTos,
    pktcSigTosFormatSelector,
    pktcSignalingType,
    pktcSignalingVersion,
    pktcSignalingVendorExtension,
    pktcSigEndPntCapabilityIndex,
    pktcSigDefNcsReceiveUdpPort,
    pktcSigServiceClassNameUS,
    pktcSigServiceClassNameDS,
    pktcSigServiceClassNameMask,
    pktcSigNcsServiceFlowState,
    pktcSigDevR1Cadence,
    pktcSigDevR2Cadence,
    pktcSigDevR3Cadence,
    pktcSigDevR4Cadence,
    pktcSigDevR5Cadence,
    pktcSigDevRgCadence,
    pktcSigDevRsCadence,
    pktcSigDevRtCadence
  }
  STATUS current
  DESCRIPTION
    "Group of objects for the common portion of the
    PacketCable Signaling MIB."
  ::= { pktcSigGroups 1 }
```

```
pktcNcsGroup OBJECT-GROUP
  OBJECTS {
    pktcNcsEndPntConfigCallAgentId,
    pktcNcsEndPntConfigCallAgentUdpPort,
    pktcNcsEndPntConfigPartialDialTO,
    pktcNcsEndPntConfigCriticalDialTO,
    pktcNcsEndPntConfigBusyToneTO,
    pktcNcsEndPntConfigDialToneTO,
    pktcNcsEndPntConfigMessageWaitingTO,
    pktcNcsEndPntConfigOffHookWarnToneTO,
    pktcNcsEndPntConfigRingingTO,
    pktcNcsEndPntConfigRingBackTO,
    pktcNcsEndPntConfigReorderToneTO,
    pktcNcsEndPntConfigStutterDialToneTO,
    pktcNcsEndPntConfigTSMMax,
    pktcNcsEndPntConfigMax1,
    pktcNcsEndPntConfigMax2,
    pktcNcsEndPntConfigMax1QEnable,
    pktcNcsEndPntConfigMax2QEnable,
    pktcNcsEndPntConfigMWD,
    pktcNcsEndPntConfigTdinit,
    pktcNcsEndPntConfigTdmin,
    pktcNcsEndPntConfigTdmax,
    pktcNcsEndPntConfigRtoMax,
    pktcNcsEndPntConfigRtoInit,
    pktcNcsEndPntConfigLongDurationKeepAlive,
    pktcNcsEndPntConfigThist,
    pktcNcsEndPntConfigStatus,
    pktcNcsEndPntConfigCallWaitingMaxRep,
    pktcNcsEndPntConfigCallWaitingDelay,
    pktcNcsEndPntStatusCallIpAddress,
    pktcNcsEndPntStatusError
  }
  STATUS current
  DESCRIPTION
    "Group of objects for the NCS portion of the
    PacketCable Signaling MIB. This is mandatory for
    NCS signaling."
  ::= { pktcSigGroups 2 }

END
```

Appendix A. Revision History

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I03-011221.

ECN	Date Ratified	Summary
mib-n-01187	12/3/01	Correct MIB error in sec-n-1029, and complete deletion of the mean deviation objects. These are MIB corrections that were driven by the security team.
prov-n-01039	5/7/01	In the Provisioning specification (PKT-SP-PROV-I02-010323), it is not clear that the config file MUST be rejected if the required info is not there. Also, the CMS table in the MTA MIB does not contain the realm name, but an index into the realm table. This should be reflected in the config file table.

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I04-021018:

ECN	Date Ratified	Summary
mib-n-02134	7/29/02	Specifies the string length for service class name used in Signaling MIB specifications.
mibmta-n-02083	6/24/02	This ECR makes I03 MIB specification and I05 security specification consistent.
mibsig-n-02043	6/24/02	Correcting references to Security Spec; R0, R6 and R7 Cadence parameters are made mandatory
mib-n-02118	7/15/02	The list of the CODECs in the “PktcCodecType” TEXTUAL-CONVENTION in the Signaling MIB is not consistent with the CODEC list in CODEC spec (codec-n-01228).

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I05-021127:

ECN	Date Ratified	Summary
mibsig-n-02203	11/18/02	Changes MIB syntax INTEGER to Integer32 in Signaling and MTA MIB specifications.

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I06-030415:

ECN	Date Ratified	Summary
mibsig-n-02222	1/20/03	Default value changed to match the description of the Ringsplash(rs) and R5 cadence MIB. Clarified requirement clarification in 64-bit Cadence representation..
mibsig-n-03050	5/19/03	The ECR accumulates changes required in the MIB SIG Specification for syntactical correctness

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I07-030728:

ECN	Date Ratified	Summary
mibsig-n-03049	6/30/03	Clarifies the usage of pktcNcsEndPntStatusError MIB object when no security association involved.

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I08-040113:

ECN	Date Ratified	Summary
mibsig-n-03081	11/24/03	Clarifies misleading requirement, specifically the string size range for pktcSigServiceClassNameUS and pktcSigServiceClassName DS.