

# PacketCable™ Signaling MIB Specification

**PKT-SP-MIB-SIG-C01-071129**

**CLOSED**

## **Notice**

This PacketCable specification is the result of a cooperative effort undertaken at the direction of Cable Television Laboratories, Inc. for the benefit of the cable industry and its customers. This document may contain references to other documents not owned or controlled by CableLabs. Use and understanding of this document may require access to such other documents. Designing, manufacturing, distributing, using, selling, or servicing products, or providing services, based on this document may require intellectual property licenses from third parties for technology referenced in this document.

Neither CableLabs nor any member company is responsible to any party for any liability of any nature whatsoever resulting from or arising out of use or reliance upon this document, or any document referenced herein. This document is furnished on an "AS IS" basis and neither CableLabs nor its members provides any representation or warranty, express or implied, regarding the accuracy, completeness, noninfringement, or fitness for a particular purpose of this document, or any document referenced herein.

© Copyright 1999 - 2007 Cable Television Laboratories, Inc.  
All rights reserved.

## Document Status Sheet

Document Control Number: PKT-SP-MIB-SIG-C01-071129				
Document Title: PacketCable™ Signaling MIB Specification				
Revision History: I01 — Released December 1, 1999				
I02 — Released March 23, 2001				
I03 — Released December 21, 2001				
I04 — Released October 18, 2002				
I05 — Released November 27, 2002				
I06 — Released April 15, 2003				
I07 — Released July 28, 2003				
I08 — Released January 13, 2004				
I09 — Released August 12, 2005				
C01 - Closed November 29, 2007				
Date: November 29, 2007				
Status:	<del>Work in Progress</del>	<del>Draft</del>	Issued	Closed
Distribution Restrictions:	<del>Author Only</del>	<del>CL/ Member</del>	<del>CL/ PacketCable Vendor</del>	Public

**Key to Document Status Codes:**

- Work in Progress**    An incomplete document, designed to guide discussion and generate feedback, that may include several alternative requirements for consideration.
- Draft**                    A document in specification format considered largely complete, but lacking review by Members and vendors. Drafts are susceptible to substantial change during the review process.
- Issued**                    A stable document, which has undergone rigorous member and vendor review and is suitable for product design and development, cross-vendor interoperability, and for certification testing.
- Closed**                    A static document, reviewed, tested, validated, and closed to further engineering change requests to the specification through CableLabs.

**Trademarks**

CableLabs®, DOCSIS®, EuroDOCSIS™, eDOCSIS™, M-CMTS™, PacketCable™, EuroPacketCable™, PCMM™, CableHome®, CableOffice™, OpenCable™, OCAP™, CableCARD™, M-Card™, and DCAS™ are trademarks of Cable Television Laboratories, Inc.

**CONTENTS**

- 1 SCOPE .....1**
- 2 REFERENCES .....1**
  - 2.1 Normative References .....1**
  - 2.2 Informative References .....1**
- 3 ABBREVIATIONS .....1**
- 4 REQUIREMENTS .....2**
- APPENDIX A. REVISION HISTORY .....25**

This page left blank intentionally.

## 1 SCOPE

This specification describes the PacketCable Signaling (SIG) MIB requirements.

## 2 REFERENCES

In order to claim compliance with this specification, it is necessary to conform to the following standards and other works as indicated, in addition to the other requirements of this specification. Notwithstanding, intellectual property rights may be required to use or implement such normative references.

### 2.1 Normative References

- [1] PacketCable MIB Framework, PKT-SP-MIBS-C01-071129, November 29, 2007, Cable Television Laboratories, Inc., <http://www.packetcable.com/>
- [2] PacketCable Network-Based Call Signaling Protocol Specification, PKT-SP-EC-MGCP-C01-071129, November 29, 2007, Cable Television Laboratories, Inc., <http://www.packetcable.com/>
- [3] PacketCable MTA Device Provisioning Specification, PKT-SP-PROV-C01-071129, November 29, 2007, Cable Television Laboratories, Inc., <http://www.packetcable.com/>

### 2.2 Informative References

- [4] PacketCable Architecture Framework Technical Report, PKT-TR-ARCH-C01-071129, November 29, 2007, Cable Television Laboratories Inc., <http://www.packetcable.com/>
- [5] IETF RFC 3261, SIP: Session Initiation Protocol, February 2002.

## 3 ABBREVIATIONS

There are no abbreviations used in this document.

## 4 REQUIREMENTS

The PacketCable NCS MIB MUST be implemented as defined below.

```

PKTC-SIG-MIB DEFINITIONS ::= BEGIN

IMPORTS
    MODULE-IDENTITY,
    OBJECT-TYPE,
    Integer32,
    IPAddress,
    BITS
        FROM SNMPv2-SMI
    TEXTUAL-CONVENTION,
    RowStatus,
    TruthValue
        FROM SNMPv2-TC
    OBJECT-GROUP,
    MODULE-COMPLIANCE
        FROM SNMPv2-CONF
    SnmpAdminString
        FROM SNMP-FRAMEWORK-MIB
    clabProjPacketCable
        FROM CLAB-DEF-MIB
    ifIndex
        FROM IF-MIB;

pktcSigMib MODULE-IDENTITY
    LAST-UPDATED      "200711290000Z" -- November 29, 2007
    ORGANIZATION      "CableLabs -- PacketCable OSS Group"
    CONTACT-INFO
        "Sumanth Channabasappa
        Postal: CableLabs, Inc.
              858 Coal Creek Circle
              Louisville, CO 80027-1266
              U.S.A.
        Phone: +1 303-661-9100
        Fax:   +1 303-661-9199
        E-mail: mibs@cablelabs.com"

DESCRIPTION
    "This MIB module supplies the basic management
    object for the PacketCable Signaling
    protocols. This version of the MIB includes
    common signaling and Network Call Signaling
    (NCS) related signaling objects.
    Acknowledgements:
    Angela Lyda      Arris Interactive
    Sasha Medvinsky  Motorola
    Roy Spitzer      Telogy Networks, Inc.
    Rick Vetter      Motorola
    Itay Sherman     Texas Instruments
    Klaus Hermanns   Cisco Systems
    Eugene Nechamkin  Broadcom Corp.
    Satish Kumar      Texas Instruments
    Copyright 1999-2007 Cable Television Laboratories, Inc.
    All rights reserved."
    REVISION "200711290000Z"
    DESCRIPTION
        "This revision, published as part of the PacketCable
  
```

```
        Signaling MIB C01 Specification."
 ::= { clabProjPacketCable 2 }

PktcCodecType ::= TEXTUAL-CONVENTION
  STATUS      current
  DESCRIPTION
    "Textual Convention defines various types of
    CODECs that MAY be supported. The list of CODECs
    MUST be consistent with the Codec RTP MAP Parameters
    Table in the PacketCable CODEC specification. In-line
    embedded comments below contain the Literal Codec Name
    for each CODEC. The Literal Codec Name corresponds to
    the second column of the Codec RTP MAP Parameters Table.
    The Literal Codec Name Column contains the CODEC name
    that is used in the LCD of the NCS messages CRCX/MDCX,
    and is also used to identify the CODEC in the CMS
    Provisioning Specification. The RTP Map Parameter
    Column of the Codec RTP MAP Parameters Table contains
    the string used in the media attribute line ('a=') of the
    SDP parameters in NCS messages."
  REFERENCE
    "PacketCable CODEC Specification"
  SYNTAX INTEGER {
    other      (1),
    unknown   (2),
    g729      (3), -- G729
    reserved  (4), -- reserved for future use
    g729E     (5), -- G729E
    pcmu      (6), -- PCMU
    g726at32  (7), -- G726-32
    g728      (8), -- G728
    pcma      (9), -- PCMA
    g726at16  (10), -- G726-16
    g726at24  (11), -- G726-24
    g726at40  (12) -- G726-40
  }

PktcRingCadence ::= TEXTUAL-CONVENTION
  STATUS      current
  DESCRIPTION
    "This object represents a ring cadence in bit string
    format. The ring cadence representation starts with the
    first 1 in the pattern (the leading 0s in the MSB are
    padding and are to be ignored). Each bit
    represents 100ms of tone; 1 is tone, 0 is no tone. 64
    bits MUST be used for cadence representation, LSB 4 bits
    are used for representing repeatable characteristics.
    0000 means repeatable, and 1000 means non repeatable.
    During SNMP SET operations 64 bits MUST be used,
    otherwise MTA MUST reject the value. As an example, the
    hex representation of a ring cadence of 0.5 secs on; 4
    secs off; repeatable would be:0x0001F00000000000."
  SYNTAX BITS {
    interval1 (0),
    interval2 (1),
    interval3 (2),
    interval4 (3),
    interval5 (4),
    interval6 (5),
    interval7 (6),
    interval8 (7),
    interval9 (8),
    interval10 (9),
  }
```

```
    interval11 (10),
    interval12 (11),
    interval13 (12),
    interval14 (13),
    interval15 (14),
    interval16 (15),
    interval17 (16),
    interval18 (17),
    interval19 (18),
    interval20 (19),
    interval21 (20),
    interval22 (21),
    interval23 (22),
    interval24 (23),
    interval25 (24),
    interval26 (25),
    interval27 (26),
    interval28 (27),
    interval29 (28),
    interval30 (29),
    interval31 (30),
    interval32 (31),
    interval33 (32),
    interval34 (33),
    interval35 (34),
    interval36 (35),
    interval37 (36),
    interval38 (37),
    interval39 (38),
    interval40 (39),
    interval41 (40),
    interval42 (41),
    interval43 (42),
    interval44 (43),
    interval45 (44),
    interval46 (45),
    interval47 (46),
    interval48 (47),
    interval49 (48),
    interval50 (49),
    interval51 (50),
    interval52 (51),
    interval53 (52),
    interval54 (53),
    interval55 (54),
    interval56 (55),
    interval57 (56),
    interval58 (57),
    interval59 (58),
    interval60 (59),
    interval61 (60),
    interval62 (61),
    interval63 (62),
    interval64 (63)
}
```

```
PktcSigType ::= TEXTUAL-CONVENTION
    STATUS      current
    DESCRIPTION
        "These are the various types of signaling that
         may be supported.
         ncs - network call signaling a derivation of MGCP"
```

```

        (Media Gateway Control Protocol) version 1.0
        dcs - distributed call signaling a derivation
        of SIP (Session Initiation Protocol) RFC 3261"
SYNTAX INTEGER {
    other(1),
    unknown(2),
    ncs(3),
    dcs(4)
}

pktcSigMibObjects          OBJECT IDENTIFIER
                           ::= { pktcSigMib 1 }
pktcSigDevConfigObjects   OBJECT IDENTIFIER
                           ::= { pktcSigMibObjects 1 }
pktcNcsEndPntConfigObjects OBJECT IDENTIFIER
                           ::= { pktcSigMibObjects 2 }
pktcSigEndPntConfigObjects OBJECT IDENTIFIER
                           ::= { pktcSigMibObjects 3 }
pktcDcsEndPntConfigObjects OBJECT IDENTIFIER
                           ::= { pktcSigMibObjects 4 }

--
--     The pktcSigDevCodecTable defines the codecs supported by this
--     Media Terminal Adapter (MTA).  There is one entry for each
--     codecs supported.
--

pktcSigDevCodecTable      OBJECT-TYPE
    SYNTAX          SEQUENCE OF PktcSigDevCodecEntry
    MAX-ACCESS      not-accessible
    STATUS          current
    DESCRIPTION
        "This table describes the MTA supported codec types."
    ::= { pktcSigDevConfigObjects 1 }

pktcSigDevCodecEntry      OBJECT-TYPE
    SYNTAX          PktcSigDevCodecEntry
    MAX-ACCESS      not-accessible
    STATUS          current
    DESCRIPTION
        "List of supported codecs types for the MTA."
    INDEX { pktcSigDevCodecIndex }
    ::= { pktcSigDevCodecTable 1 }

PktcSigDevCodecEntry ::= SEQUENCE {
    pktcSigDevCodecIndex  Integer32,
    pktcSigDevCodecType   PktcCodecType,
    pktcSigDevCodecMax    Integer32
}

pktcSigDevCodecIndex      OBJECT-TYPE
    SYNTAX          Integer32 (1..16383)
    MAX-ACCESS      not-accessible
    STATUS          current
    DESCRIPTION
        "The index value which uniquely identifies an entry
        in the pktcSigDevCodecTable."
    ::= { pktcSigDevCodecEntry 1 }

pktcSigDevCodecType       OBJECT-TYPE
    SYNTAX          PktcCodecType
    MAX-ACCESS      read-only

```

```

STATUS          current
DESCRIPTION
    "A codec type supported by this MTA."
 ::= { pktcSigDevCodecEntry 2 }

pktcSigDevCodecMax OBJECT-TYPE
SYNTAX          Integer32(1..16383)
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "The maximum number of simultaneous sessions of the
     specific codec that the MTA can support"
 ::= { pktcSigDevCodecEntry 3 }

--
--   These are the common signaling related definitions that affect
--   the entire MTA device.
--

pktcSigDevEchoCancellation OBJECT-TYPE
SYNTAX          TruthValue
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object specifies if the device is capable
     of echo cancellation."
 ::= { pktcSigDevConfigObjects 2 }

pktcSigDevSilenceSuppression OBJECT-TYPE
SYNTAX          TruthValue
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object specifies if the device is capable of
     silence suppression (Voice Activity Detection)."
 ::= { pktcSigDevConfigObjects 3 }

pktcSigDevConnectionMode      OBJECT-TYPE
SYNTAX BITS {
    voice(0),
    fax(1),
    modem(2)
}
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object specifies the connection modes that the
     MTA device can support."
 ::= { pktcSigDevConfigObjects 4 }

--
--   In the United States Ring Cadences 0, 6, and 7 are custom
--   ring cadences definable by the user. The following three
--   objects are used for these definitions.
--

pktcSigDevR0Cadence          OBJECT-TYPE
SYNTAX          PktcRingCadence
MAX-ACCESS      read-write
STATUS          current
DESCRIPTION

```



```

pktcSigDefMediaStreamTos OBJECT-TYPE
    SYNTAX      Integer32 (0..63)
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION

        "This object contains the default value used in the IP
        header for setting the Type of Service (TOS) for media
        stream packets. The MTA MUST NOT update this object with
        the value supplied by the CMS in the NCS messages (if
        present). When the value of this object is updated by
        SNMP, the MTA MUST use the new value as a default starting
        from the new connection. Existing connections are not
        affected by the value's update."

    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 0 }
    ::= { pktcSigDevConfigObjects 9 }

pktcSigTosFormatSelector OBJECT-TYPE
    SYNTAX      INTEGER {
        ipv4TOSOctet(1),
        dscpCodepoint(2)
    }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "The format of the default signaling and media
        Type of Service (TOS) values."
    DEFVAL { ipv4TOSOctet }
    ::= { pktcSigDevConfigObjects 10 }

--
--      pktcSigCapabilityTable - This table defines the valid signaling
--      types supported by this MTA.
--

pktcSigCapabilityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktcSigCapabilityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the signaling types by this MTA."
    ::= { pktcSigDevConfigObjects 11 }

pktcSigCapabilityEntry OBJECT-TYPE
    SYNTAX      PktcSigCapabilityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Entries in pktcMtaDevSigCapabilityTable - List of
        supported signaling types, versions and vendor extensions
        for this MTA. Each entry in the list provides for one
        signaling type and version combination. If the device
        supports multiple versions of the same signaling type
        it will require multiple entries."
    INDEX { pktcSignalingIndex }
    ::= { pktcSigCapabilityTable 1 }

PktcSigCapabilityEntry ::= SEQUENCE {
    pktcSignalingIndex      Integer32,
    pktcSignalingType       PktcSigType,
    pktcSignalingVersion    SnmpAdminString,

```

```
pktcSignalingVendorExtension  SnmpAdminString
}

pktcSignalingIndex            OBJECT-TYPE
SYNTAX                        Integer32 (1..16383)
MAX-ACCESS                    not-accessible
STATUS                        current
DESCRIPTION
    "The index value which uniquely identifies
    an entry in the pktcSigCapabilityTable."
 ::= { pktcSigCapabilityEntry 1 }

pktcSignalingType             OBJECT-TYPE
SYNTAX                        PkctlSigType
MAX-ACCESS                    read-only
STATUS                        current
DESCRIPTION
    "The Type identifies the type of signaling
    used, this can be NCS, DCS, etc. This value
    has to be associated with a single signaling
    version - reference pkctlMtaDevSignalingVersion."
 ::= { pktcSigCapabilityEntry 2 }

pktcSignalingVersion          OBJECT-TYPE
SYNTAX                        SnmpAdminString
MAX-ACCESS                    read-only
STATUS                        current
DESCRIPTION
    "Provides the version of the signaling type -
    reference pkctlSignalingType. Examples
    would be 1.0 or 2.33 etc."
 ::= { pktcSigCapabilityEntry 3 }

pktcSignalingVendorExtension  OBJECT-TYPE
SYNTAX                        SnmpAdminString
MAX-ACCESS                    read-only
STATUS                        current
DESCRIPTION
    "The vendor extension allows vendors to
    provide a list of additional capabilities,
    vendors can decide how to encode these
    Extensions, although space separated text is
    suggested."
 ::= { pktcSigCapabilityEntry 4 }

pkctlSigDefNcsReceiveUdpPort  OBJECT-TYPE
SYNTAX                        Integer32 (1025..65535)
MAX-ACCESS                    read-only
STATUS                        current
DESCRIPTION
    "This object contains the MTA User Datagram Protocol
    (UDP) receive port that is being used for NCS call
    signaling. This object should only be changed by the
    configuration file."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 2427 }
 ::= { pkctlSigDevConfigObjects 12 }

pkctlSigServiceClassNameUS    OBJECT-TYPE
SYNTAX                        SnmpAdminString (SIZE (0..15))
MAX-ACCESS                    read-write
STATUS                        obsolete
```

## DESCRIPTION

"This object contains a string indicating the Service Class name to create an Upstream Service (US) Flow for NCS. If the object has an empty string value then the upstream NCS SF is not created and the best effort SF is used for upstream NCS data. The creation of the NCS SF primary occurs before Voice Communication Service is activated on the device. If this object is set to a non-empty (non-zero length) string, the MTA MUST create the NCS SF if it does not currently exist and the pktcSigServiceClassNameMask object has a non-zero value. If this object is subsequently set to an empty (zero-length) string, the MTA MUST delete the NCS SF if it exists. Setting this object to a different value does not cause the Upstream Service Flow to be re-created. The string MUST contain printable ASCII characters. The length of the string does not include a terminating zero. The MTA MUST append a terminating zero when the MTA creates the service flow. "

```
::= { pktcSigDevConfigObjects 13 }
```

```
pktcSigServiceClassNameDS OBJECT-TYPE
```

```
SYNTAX SnmpAdminString (SIZE (0..15))
```

```
MAX-ACCESS read-write
```

```
STATUS obsolete
```

## DESCRIPTION

"This object contains a string indicating the Service Class Name to create a Downstream Service Flow for NCS. If the object has an empty string value then the NCS SF is not created and the best effort primary SF is used for downstream NCS data. The creation of the NCS SF occurs before Voice Communication Service is activated on the device. If this object is set to a non-empty (non-zero length) string, the MTA MUST create the NCS SF if it does not currently exist and the pktcSigServiceClassNameMask object has a non-zero value. If this object is subsequently set to an empty (zero-length) string, the MTA MUST delete the NCS SF if it exists. Setting this object to a different value does not cause the Downstream Service Flow to be re-created. The string MUST contain printable ASCII characters. The length of the string does not include a terminating zero. The MTA MUST append a terminating zero when the MTA creates the service flow. "

```
::= { pktcSigDevConfigObjects 14 }
```

```
pktcSigServiceClassNameMask OBJECT-TYPE
```

```
SYNTAX Integer32
```

```
MAX-ACCESS read-write
```

```
STATUS obsolete
```

## DESCRIPTION

"This object contains a value for the Call Signaling Network Mask. The value is used as the NCS Call Signaling classifier mask. The object is used to delete the NCS SF when set to zero. When the object is set to a non-zero value by the SNMP Manager, the NCS SF are to be created."

```
DEFVAL { 0 }
```

```
::= { pktcSigDevConfigObjects 15 }
```

```
pktcSigNcsServiceFlowState OBJECT-TYPE
```

```
SYNTAX INTEGER {
```

```
notactive (1),
```

```
active (2),
```

```
error (3)
```







```

pktcSigEndPntCapabilityIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..16383)
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "The associated index value in the pktcSigCapablityTable."
    ::= { pktcSigEndPntConfigEntry 1 }
--
-- The NCS End Point Config Table is used to define attributes that
-- are specific to connection EndPoints.
--
--

pktcNcsEndPntConfigTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PktnCsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This table describes the PacketCable EndPoint selected
        signaling type. The number of entries in this table
        represents the number of provisioned end points.
        For each conceptual row of pktcSigEndPntConfigTable
        defined, an associated row MUST be defined in one of
        the specific signaling tables such as
        pktcNcsEndPntConfigTable."
    ::= { pktcNcsEndPntConfigObjects 1 }

pktcNcsEndPntConfigEntry OBJECT-TYPE
    SYNTAX      PktnCsEndPntConfigEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Entries in pktcNcsEndPntConfigTable - Each entry
        describes what signaling type a particular endpoint uses."
    INDEX { ifIndex }
    ::= { pktcNcsEndPntConfigTable 1 }

PktnCsEndPntConfigEntry ::= SEQUENCE {
    pktcNcsEndPntConfigCallAgentId          SnmpAdminString,
    pktcNcsEndPntConfigCallAgentUdpPort    Integer32,
    pktcNcsEndPntConfigPartialDialTO       Integer32,
    pktcNcsEndPntConfigCriticalDialTO      Integer32,
    pktcNcsEndPntConfigBusyToneTO         Integer32,
    pktcNcsEndPntConfigDialToneTO         Integer32,
    pktcNcsEndPntConfigMessageWaitingTO    Integer32,
    pktcNcsEndPntConfigOffHookWarnToneTO   Integer32,
    pktcNcsEndPntConfigRingingTO           Integer32,
    pktcNcsEndPntConfigRingBackTO         Integer32,
    pktcNcsEndPntConfigReorderToneTO      Integer32,
    pktcNcsEndPntConfigStutterDialToneTO   Integer32,
    pktcNcsEndPntConfigTSMMax              Integer32,
    pktcNcsEndPntConfigMax1                Integer32,
    pktcNcsEndPntConfigMax2                Integer32,
    pktcNcsEndPntConfigMax1QEnable         TruthValue,
    pktcNcsEndPntConfigMax2QEnable         TruthValue,
    pktcNcsEndPntConfigMWD                 Integer32,
    pktcNcsEndPntConfigTdinit              Integer32,
    pktcNcsEndPntConfigTdmin                Integer32,
    pktcNcsEndPntConfigTdmax                Integer32,
    pktcNcsEndPntConfigRtoMax              Integer32,
    pktcNcsEndPntConfigRtoInit             Integer32,
    pktcNcsEndPntConfigLongDurationKeepAlive Integer32,
    pktcNcsEndPntConfigThist               Integer32,

```

```

pktcNcsEndPntConfigStatus          RowStatus,
pktcNcsEndPntConfigCallWaitingMaxRep  Integer32,
pktcNcsEndPntConfigCallWaitingDelay  Integer32,
pktcNcsEndPntStatusCallIpAddress     IPAddress,
pktcNcsEndPntStatusError             INTEGER
}

```

```

pktcNcsEndPntConfigCallAgentId      OBJECT-TYPE
SYNTAX          SnmpAdminString(SIZE (3..255))
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains a string indicating the call agent
    name(e.g.: ca@abc.def.com). The call agent name
    after the character '@', MUST be a fully qualified
    domain name and MUST have a corresponding
    pktcMtaDevCmsFqdn entry in the pktcMtaDevCmsTable. For
    each particular end-point, the MTA MUST use the current
    value of this object to communicate with the corresponding
    CMS. The MTA MUST update this object with the value of the
    'Notified Entity' parameter of the NCS message. Because of the high
importance of this object to
    the ability of the MTA to maintain reliable NCS
    communication with the CMS, it is highly recommended not
    to change this object's value through management station
    during normal operations."

```

```
 ::= { pktcNcsEndPntConfigEntry 1 }
```

```

pktcNcsEndPntConfigCallAgentUdpPort  OBJECT-TYPE
SYNTAX          Integer32 (1025..65535)
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains the current value of the User
    Datagram Protocol (UDP) receive port on which the call
    agent will receive NCS signaling from the endpoint.
    For each particular end-point, the MTA MUST use
    the current value of this object to communicate with the
    corresponding CMS. The MTA MUST update this
    object with the value of the 'Notified Entity' parameter
    of the NCS message. If the Notified Entity
    parameter does not contain a CallAgent port, the MTA MUST
    update this object with default value of 2727.
    Because of the high importance of this object to the
    ability of the MTA to maintain reliable NCS communication
    with the CMS, it is highly recommended not to change this
    object's value through management station during normal
    operations."
REFERENCE
    "Refer to NCS specification"
DEFVAL          { 2727 }
 ::= { pktcNcsEndPntConfigEntry 2 }

```

```

pktcNcsEndPntConfigPartialDialTO     OBJECT-TYPE
SYNTAX          Integer32
UNITS           "seconds"
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains maximum value of the partial
    dial time out."
REFERENCE

```

```

    "Refer to PacketCable NCS specification"
    DEFVAL { 16 }
    ::= { pktcNcsEndPntConfigEntry 3 }

```

```

pktcNcsEndPntConfigCriticalDialTO      OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the maximum value of the critical
        dial time out."
    REFERENCE
        "Refer NCS specification"
    DEFVAL { 4 }
    ::= { pktcNcsEndPntConfigEntry 4 }

```

```

pktcNcsEndPntConfigBusyToneTO         OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the default timeout value for busy
        tone.The MTA MUST NOT update this object with the
        value provided in the NCS Message (if present).
        If the value of the object is modified by the
        SNMP Management Station, the MTA MUST use the new value as
        a default only for a new signal requested by the NCS
        message."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL { 30 }
    ::= { pktcNcsEndPntConfigEntry 5 }

```

```

pktcNcsEndPntConfigDialToneTO         OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the default timeout value for dial
        tone. The MTA MUST NOT update this object with
        the value provided in the NCS Message (if present).
        If the value of the object is modified by the
        SNMP Management Station, the MTA MUST use the new value
        as a default only for a new signal requested by the NCS
        message."
    REFERENCE
        "Refer to NCS specification "
    DEFVAL { 16 }
    ::= { pktcNcsEndPntConfigEntry 6 }

```

```

pktcNcsEndPntConfigMessageWaitingTO   OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the default timeout value for
        message waiting indicator The MTA MUST NOT
        update this object with the value provided in the NCS

```

Message (if present). If the value of the object is modified by the SNMP Management Station, the MTA MUST use the new value as a default only for a new signal requested by the NCS message."

## REFERENCE

"Refer to NCS specification"

DEFVAL { 16 }

::= { pktcNcsEndPntConfigEntry 7 }

pktcNcsEndPntConfigOffHookWarnToneTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

## DESCRIPTION

"This object contains the default timeout value for the off hook Warning tone. The MTA MUST NOT update this object with the value provided in the NCS Message (if present). If the value of the object is modified by the SNMP Management Station, the MTA MUST use the new value as a default only for a new signal requested by the NCS message. "

## REFERENCE

"Refer to NCS specification"

DEFVAL { 0 }

::= { pktcNcsEndPntConfigEntry 8 }

pktcNcsEndPntConfigRingingTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

## DESCRIPTION

"This object contains the default timeout value for ringing. The MTA MUST NOT update this object with the value provided in the NCS Message (if present). If the value of the object is modified by the SNMP Management Station, the MTA MUST use the new value as a default only for a new signal requested by the NCS message."

## REFERENCE

"Refer to NCS specification"

DEFVAL { 180 }

::= { pktcNcsEndPntConfigEntry 9 }

pktcNcsEndPntConfigRingBackTO OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

## DESCRIPTION

"This object contains the default timeout value for ring back. The MTA MUST NOT update this object with the value provided in the NCS Message (if present). If the value of the object is modified by the SNMP Management Station, the MTA MUST use the new value as a default only for a new signal requested by the NCS message."

## REFERENCE

"Refer to NCS specification"

DEFVAL { 180 }

::= { pktcNcsEndPntConfigEntry 10 }

```

pktcNcsEndPntConfigReorderToneTO      OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the default timeout value for
        reorder tone. The MTA MUST NOT update this
        object with the value provided in the NCS Message (if
        present).  If the value of the object is modified
        by the SNMP Management Station, the MTA MUST use the new
        value as a default only for a new signal requested by
        the NCS message."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 30 }
    ::= { pktcNcsEndPntConfigEntry 11 }

pktcNcsEndPntConfigStutterDialToneTO   OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "seconds"
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the default timeout value for
        stutter dial tone. The MTA MUST NOT update this
        object with the value provided in the NCS Message (if
        present).  If the value of the object is modified
        by the SNMP Management Station, the MTA MUST use the new
        value as a default only for a new signal requested by the
        NCS message."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 16 }
    ::= { pktcNcsEndPntConfigEntry 12 }

pktcNcsEndPntConfigTSMMax              OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the max time in seconds since the
        sending of the initial datagram."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 20 }
    ::= { pktcNcsEndPntConfigEntry 13 }

pktcNcsEndPntConfigMax1                OBJECT-TYPE
    SYNTAX      Integer32
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object contains the suspicious error threshold
        for signaling messages."
    REFERENCE
        "Refer to NCS specification"
    DEFVAL      { 5 }
    ::= { pktcNcsEndPntConfigEntry 14 }

pktcNcsEndPntConfigMax2                OBJECT-TYPE
    SYNTAX      Integer32

```

```
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the disconnect error
              threshold for signaling messages."
REFERENCE    "Refer to NCS specification"
DEFVAL      { 7 }
 ::= { pktcNcsEndPntConfigEntry 15 }

pktcNcsEndPntConfigMax1QEnable    OBJECT-TYPE
SYNTAX        TruthValue
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object enables/disables the Max1 Domain Name
              Server (DNS) query operation when Max1 expires."
DEFVAL      { true }
 ::= { pktcNcsEndPntConfigEntry 16 }

pktcNcsEndPntConfigMax2QEnable    OBJECT-TYPE
SYNTAX        TruthValue
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object enables/disables the Max2 DNS query
              operation when Max2 expires."
DEFVAL      { true }
 ::= { pktcNcsEndPntConfigEntry 17 }

pktcNcsEndPntConfigMWD            OBJECT-TYPE
SYNTAX        Integer32
UNITS         "seconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "Maximum Waiting Delay (MWD) contains the maximum
              number of seconds a MTA waits after a restart."
REFERENCE    "Refer to NCS specification"
DEFVAL      { 600 }
 ::= { pktcNcsEndPntConfigEntry 18 }

pktcNcsEndPntConfigTdinit        OBJECT-TYPE
SYNTAX        Integer32
UNITS         "seconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION   "This object contains the initial number of seconds
              a MTA waits after a disconnect."
REFERENCE    "Refer to NCS specification"
DEFVAL      { 15 }
 ::= { pktcNcsEndPntConfigEntry 19 }

pktcNcsEndPntConfigTdmin         OBJECT-TYPE
SYNTAX        Integer32
UNITS         "seconds"
MAX-ACCESS    read-create
STATUS        current
DESCRIPTION
```

"This object contains the minimum number of seconds a MTA waits after a disconnect."

REFERENCE

"Refer to NCS specification"

DEFVAL { 15 }

::= { pktcNcsEndPntConfigEntry 20 }

pktcNcsEndPntConfigTdma OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the maximum number of seconds a MTA waits after a disconnect."

REFERENCE

"Refer to NCS specification"

DEFVAL { 600 }

::= { pktcNcsEndPntConfigEntry 21 }

pktcNcsEndPntConfigRtoMax OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the maximum number of seconds for the retransmission timer."

REFERENCE

"Refer to NCS specification"

DEFVAL { 4 }

::= { pktcNcsEndPntConfigEntry 22 }

pktcNcsEndPntConfigRtoInit OBJECT-TYPE

SYNTAX Integer32

UNITS "milliseconds"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object contains the initial number of seconds for the retransmission timer."

REFERENCE

"Refer to NCS specification"

DEFVAL { 200 }

::= { pktcNcsEndPntConfigEntry 23 }

pktcNcsEndPntConfigLongDurationKeepAlive OBJECT-TYPE

SYNTAX Integer32

UNITS "minutes"

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"Specifies a timeout value in minutes for sending long duration call notification message."

REFERENCE

"Refer to NCS specification"

DEFVAL { 60 }

::= { pktcNcsEndPntConfigEntry 24 }

pktcNcsEndPntConfigThist OBJECT-TYPE

SYNTAX Integer32

UNITS "seconds"

```
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "Timeout period in seconds before no response is
    declared."
REFERENCE
    "Refer to NCS specification"
DEFVAL { 30 }
 ::= { pktcNcsEndPntConfigEntry 25 }

pktcNcsEndPntConfigStatus      OBJECT-TYPE
SYNTAX          RowStatus
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains the Row Status associated with
    the pktcNcsEndPntConfigTable."
 ::= { pktcNcsEndPntConfigEntry 26 }

pktcNcsEndPntConfigCallWaitingMaxRep      OBJECT-TYPE
SYNTAX          Integer32 (0..10)
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains the default value of the maximum
    number of repetitions of the call waiting tone that the
    MTA will play from a single CMS request. The MTA
    MUST NOT update this object with the information provided
    in the NCS Message (if present). If the value of
    the object is modified by the SNMP Management Station,
    the MTA MUST use the new value as a default only for a new
    signal requested by the NCS message."
DEFVAL          { 1 }
 ::= { pktcNcsEndPntConfigEntry 27 }

pktcNcsEndPntConfigCallWaitingDelay      OBJECT-TYPE
SYNTAX          Integer32 (1..100)
UNITS           "seconds"
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "This object contains the delay between repetitions
    of the call waiting tone that the MTA will play from
    a single CMS request."
DEFVAL          { 10 }
 ::= { pktcNcsEndPntConfigEntry 28 }

pktcNcsEndPntStatusCallIpAddress      OBJECT-TYPE
SYNTAX          IpAddress
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object contains the IP address of the CMS
    currently being used for this endpoint. This IP
    address is used to create the appropriate security
    association."
 ::= { pktcNcsEndPntConfigEntry 29 }

pktcNcsEndPntStatusError      OBJECT-TYPE
SYNTAX          INTEGER {
    operational          (1),
    noSecurityAssociation (2),
    disconnected          (3)
}
```

```

}
MAX-ACCESS      read-only
STATUS          current
DESCRIPTION
    "This object contains the error status for this interface.
    The operational state indicates that all operations
    necessary to put the line in service have occurred and CMS
    has acknowledged the RSIP message successfully.
    If 'pktcMtaDevCmsIpssecCtrl' is enabled for the associated
    Call Agent, the noSecurityAssociation status indicates
    that no Security Association (SA) yet exists for this
    endpoint. Otherwise, the state is unused.
    The disconnected status indicates one of the following two:
    1. If 'pktcMtaDevCmsIpssecCtrl' is disabled then no
    security association is involved with this endpoint: the
    NCS signaling Software is in process of establishing the
    NCS signaling Link via an RSIP exchange.
    2. Otherwise, pktcMtaDevCmsIpssecCtrl is enabled, the
    security Association has been established and the NCS
    signaling Software is in process of establishing the NCS
    signaling Link via an RSIP exchange."

 ::= { pktcNcsEndPntConfigEntry 30 }
--
-- notification group is for future extension.
--
pktcSigNotificationPrefix OBJECT IDENTIFIER ::= { pktcSigMib 2 }
pktcSigNotification OBJECT IDENTIFIER ::= {
    pktcSigNotificationPrefix 0 }
pktcSigConformance OBJECT IDENTIFIER ::= { pktcSigMib 3 }
pktcSigCompliances OBJECT IDENTIFIER ::= { pktcSigConformance 1 }
pktcSigGroups OBJECT IDENTIFIER ::= { pktcSigConformance 2 }

-- compliance statements

pktcSigBasicCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "The compliance statement for devices that implement Signaling
        on the MTA."

MODULE -- pktcSigMib

-- unconditionally mandatory groups

MANDATORY-GROUPS {
    pktcSigGroup
}
GROUP pktcNcsGroup
DESCRIPTION
    "This group is mandatory for any MTA implementing NCS
    signaling"
 ::= { pktcSigCompliances 1 }

-- units of conformance

pktcSigGroup OBJECT-GROUP
    OBJECTS {
        pktcSigDevCodecType,
        pktcSigDevCodecMax,
        pktcSigDevEchoCancellation,
        pktcSigDevSilenceSuppression,

```

```

pktcSigDevConnectionMode,
pktcSigDevR0Cadence,
pktcSigDevR6Cadence,
pktcSigDevR7Cadence,
pktcSigDefCallSigTos,
pktcSigDefMediaStreamTos,
pktcSigTosFormatSelector,
pktcSignalingType,
pktcSignalingVersion,
pktcSignalingVendorExtension,
pktcSigEndPntCapabilityIndex,
pktcSigDefNcsReceiveUdpPort,
pktcSigDevR1Cadence,
pktcSigDevR2Cadence,
pktcSigDevR3Cadence,
pktcSigDevR4Cadence,
pktcSigDevR5Cadence,
pktcSigDevRgCadence,
pktcSigDevRsCadence,
pktcSigDevRtCadence
}
STATUS current
DESCRIPTION
    "Group of objects for the common portion of the
    PacketCable Signaling MIB."
 ::= { pktcSigGroups 1 }

```

```

pktcNcsGroup OBJECT-GROUP
OBJECTS {
pktcNcsEndPntConfigCallAgentId,
pktcNcsEndPntConfigCallAgentUdpPort,
pktcNcsEndPntConfigPartialDialTO,
pktcNcsEndPntConfigCriticalDialTO,
pktcNcsEndPntConfigBusyToneTO,
pktcNcsEndPntConfigDialToneTO,
pktcNcsEndPntConfigMessageWaitingTO,
pktcNcsEndPntConfigOffHookWarnToneTO,
pktcNcsEndPntConfigRingingTO,
pktcNcsEndPntConfigRingBackTO,
pktcNcsEndPntConfigReorderToneTO,
pktcNcsEndPntConfigStutterDialToneTO,
pktcNcsEndPntConfigTSMMax,
pktcNcsEndPntConfigMax1,
pktcNcsEndPntConfigMax2,
pktcNcsEndPntConfigMax1QEnable,
pktcNcsEndPntConfigMax2QEnable,
pktcNcsEndPntConfigMWD,
pktcNcsEndPntConfigTdinit,
pktcNcsEndPntConfigTdmin,
pktcNcsEndPntConfigTdmax,
pktcNcsEndPntConfigRtoMax,
pktcNcsEndPntConfigRtoInit,
pktcNcsEndPntConfigLongDurationKeepAlive,
pktcNcsEndPntConfigThist,
pktcNcsEndPntConfigStatus,
pktcNcsEndPntConfigCallWaitingMaxRep,
pktcNcsEndPntConfigCallWaitingDelay,
pktcNcsEndPntStatusCallIpAddress,
pktcNcsEndPntStatusError
}
STATUS current
DESCRIPTION
    "Group of objects for the NCS portion of the

```

```
        PacketCable Signaling MIB.  This is mandatory for
        NCS signaling."
 ::= { pktcSigGroups 2 }

pktcSigObsoleteGroup  OBJECT-GROUP
  OBJECTS {
    pktcSigServiceClassNameUS,
    pktcSigServiceClassNameDS,
    pktcSigServiceClassNameMask,
    pktcSigNcsServiceFlowState
  }
  STATUS  obsolete
  DESCRIPTION
    " Collection of obsolete objects for PacketCable
    Signaling MIB."
 ::= { pktcSigGroups 3}

END
```

## Appendix A. Revision History

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I03-011221:

ECN	Date Ratified	Summary
mib-n-01187	12/3/01	Correct MIB error in sec-n-1029, and complete deletion of the mean deviation objects. These are MIB corrections that were driven by the security team.
prov-n-01039	5/7/01	In the Provisioning specification (PKT-SP-PROV-I02-010323), it is not clear that the config file MUST be rejected if the required info is not there. Also, the CMS table in the MTA MIB does not contain the realm name, but an index into the realm table. This should be reflected in the config file table.

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I04-021018:

ECN	Date Ratified	Summary
mib-n-02134	7/29/02	Specifies the string length for service class name used in Signaling MIB specifications.
mibmta-n-02083	6/24/02	This ECR makes I03 MIB specification and I05 security specification consistent.
mibsig-n-02043	6/24/02	Correcting references to Security Spec; R0,R6 and R7 Cadence parameters are made mandatory
mib-n-02118	7/15/02	The list of the CODECs in the "PktcCodecType" TEXTUAL-CONVENTION in the Signaling MIB is not consistent with the CODEC list in CODEC spec (codec-n-01228).

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I05-021127:

ECN	Date Ratified	Summary
mibsig-n-02203	11/18/02	Changes MIB syntax INTEGER to Integer32 in Signaling and MTA MIB specifications.

The following Engineering Change Notices have been incorporated into PK-SP-MIB-SIG-I06-030415:

ECN	Date Ratified	Summary
mibsig-n-02222	1/20/03	Default value changed to match the description of the Ringsplash(rs) and R5 cadence MIB. Clarified requirement clarification in 64-bit Cadence representation.
mibsig-n-03050	5/19/03	The ECR accumulates changes required in the MIB SIG Specification for syntactical correctness

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I07-030728:

<b>ECN</b>	<b>Date Ratified</b>	<b>Summary</b>
mibsig-n-03049	6/30/03	Clarifies the usage of pktcNcsEndPntStatusError MIB object when no security association involved.

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I08-040113:

<b>ECN</b>	<b>Date Ratified</b>	<b>Summary</b>
mibsig-n-03081	11/24/03	Clarifies misleading requirement, specifically the string size range for pktcSigServiceClassNameUS and pktcSigServiceClassName DS.

The following Engineering Change Notice has been incorporated into PK-SP-MIB-SIG-I09-0500812:

<b>ECN</b>	<b>Date Ratified</b>	<b>Summary</b>
MIB-SIG-N-04.0176-5	8/2/2004	Number of MIB Objects can be changed by both SNMP Management and via NCS messages. The proper logic for such Objects must be defined.